



RCI-1502 HRT Telescopic Boom System Instruction Manual

MAN-1073 Rev G



Management
System
ISO 9001:2008

www.tuv.com
ID 9105072472

LSI-Robway Pty Limited, 32 West Thebarton Road, Thebarton, South Australia, 5031
Phone: +61 (0) 8 8238 3500 Fax: +61 (0) 8 8352 1684 www.lsirobway.com.au

Contents	Page No.
1. Important Safety Notice	3
2. General Description	4
3. Operating Instructions.....	5
3.1. Turning On the RCI-1502.....	5
3.2. Turning Off the RCI-1502	5
3.3. Operating Screen.....	6
3.4. Display Functions.....	7
3.5. Data Logging and Data Downloading	9
4. Installation	10
5. Calibration.....	17
5.1. Verifying Operation of Sensors.....	20
5.2. Configuring User Variables	21
5.3. Calibrating Main Boom Angle.....	28
5.3.1. Calibrating Low Boom Angle.....	28
5.3.2. Calibrating High Boom Angle	28
5.4. Calibrating Main Boom Length.....	29
5.4.1. Calibrating Short Boom Length.....	29
5.4.2. Calibrating Long Boom Length	29
5.5. Calibrating Load on the MAIN Winch.....	30
5.5.1. Calibrating Light Main Load.....	30
5.5.2. Calibrating Heavy Main Load.....	30
5.6. Calibrating Load on the AUX. Winch (Twin Winch).....	31
5.6.1. Calibrating Light Aux Load	31
5.6.2. Calibrating Heavy Aux Load	31
5.7. Copying and Restoring Calibration Data Function	32
6. Troubleshooting.....	38
7. Electrical Specifications	45
8. Appendices.....	48

1. Important Safety Notice

The RCI-1502 System is a crane device which warns the operator of impending overload conditions and of overhoist conditions which could cause damage to property, crane and personnel.

The system is not a substitute for good operator judgement, experience and safe crane operation. The operator is solely responsible for the safe operation of the crane.

The operator must, prior to operation of the crane, read this manual carefully and thoroughly and shall ensure that all operational instructions and warnings are understood and complied with.

Proper system operation requires the operator to correctly program the RCI System to match the crane setup and working configuration.

The system is equipped with an override key which bypasses alarms and motion cut function at which time the system can no longer warn of impending overload and must only be operated strictly in accordance to the crane manufacturer's setup and operation procedures. Operation of this key is for authorised personnel only who shall be solely responsible for its use.

SPECIAL NOTE FOR TENSIO METER INSTALLATION AND USE

Please Note: Remove tensiometers during dragline and piling operations.

Tensiometers (dynamometers/line-riders) are NOT designed for use on wire ropes performing Piling operations due to the high cycle and high speeds combined with high linepulls.

Please ensure they are removed before commencing operations.

LSI-Robway and distributors will not accept responsibility for either rope or tensiometer damage resulting from this type of use.

2. General Description

This Manual contains general information, installation, operation, calibration, maintenance and parts information for the RCI-1502 Rated Capacity Indicator to suit various Telescopic boom mobile cranes.

Refer to drawing DWG 2464 "RCI-1502 GENERAL ARRANGEMENT FOR TYPICAL TELESCOPIC BOOM HRT SYSTEM" on Section 8.2. of the Manual for an overview of the System.

Drawing (DWG) Numbers, where applicable in the following Sections, are also provided for quick reference.

The RCI-1502 is a fully automatic Rated Capacity Indicator which provides a display of the following functions:

- Boom Length,
- Boom Angle,
- Hook Radius,
- S.W.L. (Safe Working Load),
- Hoist Rope Falls,
- Duty (Configuration),
- Actual Load of Selected Winch (Main or Aux),
- Percentage of SWL (3 coloured lamps - green, amber, and red).

The RCI-1502 display also provides the following features:

- Visual and audible alarms on warning (approach to overload), overload, motion-cut, two-blocking detection, and error detection,
- Self-diagnosis and error codes,
- Data-logging,
- Built-in calibration and fault-finding tools,
- Units conversion (imperial/metric) facility,
- Anti-two-block (overhoist limit) facility.

3. Operating Instructions

The following sections explain how to operate the RCI-1502 and make best use of its capabilities.

3.1. *Turning On the RCI-1502*

Power to the unit is from the crane battery (nominal 12 or 24 volts dc) through the start-up or ignition key. In some applications an additional switch may be used to enable the operator to switch the unit on/off as required.


As soon as power is applied to the unit, its display and other indicators should light up and the unit should go through its self-test operation.

3.2. *Turning OFF the Unit*

The unit will stop working as soon as the power is removed from it by switching off any of the switches indicated in Section 3.1 above.

3.3. Operating Screen

The following is the operating screen of the RCI-1502 showing the general display functions:



3.4. Display Functions

The RCI-1502 has 2 LCD display windows and 6 front panel push buttons. The display panel can also be grouped into four parts as follows:

3.4.1. "Approach to Rated Capacity" Indication Lamps

This is the uppermost part of the display which contains three coloured lamps to indicate "approach to rated capacity". Factory settings are as follows:

- Green: 50 to 84%, Amber: 85 to 99%, Red: 100 to 110%
- Amber lamp flashes when first trip point is reached (i.e. 85% Rated Capacity) plus an intermittent audible alarm.
- Red lamp will flash at 100% of rated capacity plus a continuous audible alarm.
- Red lamp will stop flashing and will stay ON when the lifted load exceeds 110% of SWL plus a continuous audible alarm. Crane motion controls are also activated at this stage if fitted.

3.4.2. Numerical LCD for Various Functions

This is a numerical LCD display, just below the indication lamps mentioned above, which shows the LENGTH, ANGLE, RADIUS, S.W.L., FALLS, and DUTY status.

This window is also used to display ERROR codes when any errors are detected. The error function cannot be manually selected but will be displayed automatically if there are any errors. Please refer to Section 6. "Troubleshooting" for the meaning and description of the error codes.

The above functions are selected by pressing the SELECT button on the front panel. The selected function is indicated by the lamp next to the labels. The display functions are as follows:

LENGTH

The numerical display shows the BOOM length, in unit selected (feet or metres), for the winch selected.

ANGLE

The numerical display shows the current working angle in degrees which is read from the main boom angle sensor.

RADIUS

The numerical display shows the current working radius, in unit selected (feet or metres), for the winch selected.

SWL

The numerical display shows the current maximum safe working load in unit selected (kilopounds or tonnes). The S.W.L. will depend on the current crane configuration (duty), winch selected (if twin winch), the maximum linepull and the falls selected.

FALLS

The numerical display shows the number of falls (*parts of line*) used for the winch selected. To change the falls, press the UP/DOWN arrow keys to ramp to the desired falls number while the FALLS indicator is on, make sure the correct winch is selected.

DUTY

The numerical display shows the current duty (or configuration) number selected. Each system manual is supplied with a DUTY LISTING for a given application. Please refer to the DUTY LISTING at the rear of the manual for a description of the duties. A plastic encapsulated version is also supplied with the system for the crane operator's quick reference in the cabin.

To change the Duty number, use the UP/DOWN key to ramp to the desired value, while the DUTY LED indicator is on.

3.4.3. A.T.B. (Anti-Two-Block) and O/RIDE (Override) Indication LEDs

This part of the display has two red LED's which shows the current status of the following functions:

- O/RIDE - LED ON when over-ride/bypass key is switched on.
- A.T.B. - LED ON when on two-blocking condition.

The RCI-1502 is supplied with a standard Anti-Two-Block (ATB) input for connecting an optional ATB sensor to prevent two-blocking. When the ATB indicator on the front panel is lit, a two-blocking condition has occurred and further hoisting is stopped by activating the motion cut relay, if installed.

3.4.4. Numerical LCD for Current Load Readout

This part has a numerical LCD which shows the current load, in unit selected (kilopounds or metric tonnes), on the winch selected.

There are three red LED's on the left side of this window. The MAIN and AUX LED's indicate which winch is selected. The LB S LED indicates the units selected. LED ON means Imperial Units (kips, feet) and LED OFF means Metric Units (tonnes, metres).

Use the WINCH SELECT button to switch between MAIN and AUX winches. For Single Winch cranes, only the MAIN winch is active and the AUX LED is disabled.

Although the RCI-1502 will always check safe operation for both winches, you should make sure that the correct winch is selected as the winch selection affects the values shown on the displays.

When the ACTUAL LOAD exceeds the SWL for the current crane configuration the RCI-1502 will activate audible and visual alarms.

If the overload is higher than the SWL % for MOTION CUT OUTPUT, set in calibration mode, the instrument will also activate the motion cut relay, if installed. This will then stop further over-loading of the crane. To bypass or temporarily disable motion cut, the operator must use the over-ride key which should be held by the site-supervisor. When the key is inserted into the display and is turned on the O/RIDE indicator is illuminated as a reminder.

LSI-Robway recommends that the over-ride key be switched OFF at all times and the over-ride key be held by the site-supervisor.

3.5 Data Logging and Data Downloading

For downloading data to PC, connect the Data-Logging Download Cable (Part No. CABCOM 1261) between the RS-232 socket at the back of the RCI-1502 display and the PC.



Please refer to Section 8.1. “DATA LOGGING ON RCI SYSTEMS” at the rear of the manual for usage information and details.

4. Installation

SETTING UP THE CRANE

Lower the crane boom to a safe and convenient position.

INSTALLING BOOM PARTS

Recoil Drum

The recoil drum contains both the angle sensor and length sensor for telescopic cranes. The payout cable of the drum is also used for wiring the ATB switch/es if required. It is supplied **for right hand side mounting** unless ordered specifically for left hand side mounting.

The recoil drum comes complete with mounting bolts, payout wire roller guides and boom tip tie-off bracket.

First remove the recoil drum cover and set aside. Fix the recoil drum and payout cable to the right hand side of the main boom by welding the mounting bolts provided to a suitable location on the side of the boom. Mount the recoil drum on the bolts ensuring that the electrical connection socket is pointing towards the cabin. Ensure the recoil drum is mounted 'squarely' to the boom side panel, this is essential to avoid incorrect payout wire spooling problems.

When the recoil drum is mounted to the left hand side of the boom, the electronic angle sensor must also be adjusted to get it working to its full range. Please refer to drawings DWG 1199, 1239, & 2159 at the rear of this manual for the correct position of the angle sensor.

Select a convenient uninterrupted payout cable alignment along the side of the boom and cut and weld the anchor post provided to a suitable position on the boom head, so that the cable can be clamped into the groove on the post to obtain a temporary line. Select positions for the intermediate cable roller guides provided, one for each telescoping section and one or more for the main boom allowing 3-4m between the drum and the nearest cable roller guide. Measure the distance from the cable to the sides of the boom sections, record lengths and mark the positions for the roller guides. Cut and weld the brackets of the guides to the sides of the boom sections after removing the cable. Refit the cable through the guides and then anchor it to the post using the clamp provided.

When the installation is complete, the recoil spring should be 'maximised' to ensure that maximum available tension is applied to the payout wire to prevent poor spooling onto the recoil drum. If possible, extend the boom fully at zero degrees and pull the recoil drum payout wire fully out by hand until the spring 'locks up'. Allow 2 metres of payout wire to return back onto the drum and cut off the excess. Remake the connection to the boom tip tie-off bracket. Remember to leave sufficient cable length for connection to the anti-2-block switch if one is being fitted.

If it is not possible to safely extend the boom at zero degrees, then simulate by extending the payout by hand to a mark on the ground representing the full telescopic extension.

Fully retract the boom. Extend the payout wire slightly and note the direction of rotation of the large gear wheel for an extending boom. Release the payout wire and allow it to retract to its fully retracted position. Turn the large aluminium gear, by hand, in the opposite direction to that noted for an extending boom, until the gear stops. Turn the gear in the opposite direction (i.e. as if for extending) for $\frac{3}{4}$ of a turn or three clicks of the clutch. Safely extend the boom to full extension ensuring continuous operation of the gear wheel and potentiometer. Fully retract the boom and again check operation. Refit the recoil drum cover and ensure all mounting nuts are tight.

Route the cable carefully from the recoil drum back around the boom pivot to the cabin. Fix the cable to the boom and turret using adequate fixings ensuring that the cable is not pinched or stretched as the boom moves through its full luffing arc. Only connect the cable to the Display Unit when finished welding.

Notes:

The slip-rings in the LSI-Robway recoil drum are designed for use with LSI-Robway Anti-2-block systems and are not for resistive or inductive circuits such as lights or bells. If you have a particular application that you feel may be applicable to the slip-ring facility, please contact LSI-Robway for further advice.

Please note also that high tensile booms require proper welding procedure specifications. Obtain specialist assistance in these cases.

Recoil drum and typical installation at the boom base section

Load Sensor (Dynamometer/Tensiometer Type)

Please Note:

Remove tensiometers during dragline and piling operations. Refer to Section 1. "Important Safety Notice" – Special Note for Tensiometer Installation & Use.

The RCI-1502 System uses a dynamometer/tensiometer (also known as line-rider) type load sensor which directly senses the line-pull generated when lifting the load.

The dynamometer, or dyno for short, is a three-pulley arrangement load sensor with a beam type load cell (model RW5000) mounted within. The dyno monitors the hoist rope line-pull as the hoist rope passes through the three sheaves. The dyno sheaves must be suited to the diameter of the hoist rope.

The dynos are usually rigidly mounted on top of the boom base section towards the outer end. They are available in both single and twin winch versions. The mounting base consists of a pair of angle irons complete with 4 off hi-tensile black bolts, nuts and spring washers. It is usual to weld the bolt heads to the boom top. Consult layout drawings at the rear of this manual for more details.

On some cranes where the angle between the boom tip and the hoist rope varies greatly as the boom luffs up and down, an articulated arm assembly (or universal arm) may be used to fix the dyno to one end of the arm and the other end of the arm bolted or fixed to the boom. This universal arm allows the dyno to follow the natural location/movement of the hoist rope relative to the boom itself. It is available at LSI-Robway or can be fabricated on site to suit application.

The load cell in the dyno will output an electrical signal proportional to the hoist rope line-pull forces, the RCI-1502 will then convert this into hook-load weight in tonnes or kilopounds. Correctly following the calibration procedures is essential for accurately determining the hook load weight.

Drawing References:

DWG 1393 – “Overall Dimensions, HRT-3MM Micro-Mini Dyno”

DWG 0875 – “General Arrangement, HRT-3MM Dynamometer”

DWG 0422 (Sheets 1-2 of 2) – “General Arrangement, HRT-3 Dyno”


DWG 0104, 0786, 0787 – “Parts List for HRT-3 Dynamometer”

DWG 0353 – “Exploded View & Parts List for HRT3-2 Double Dyno”

DWG 0552 – “General Arrangement, HRT3-2 Double Dynamometer”

DWG 0370 – “General Arrangement, Std Articulated Arm for Dyno”

DWG 2468T – “Typical Installation of Dyno on Telescopic Crane”



Typical installation of dynamometers/tensiometers on telescopic cranes

Anti-Two-Block (Optional Item)

Fix the anti-two-block (ATB) switch mounting bolt by welding it to the boom head preferably so that the bob weight (when suspended from the switch) can be fitted to the static hoist rope below the rope anchor. Check that the switch works correctly as the boom luffs throughout its working range.

Additional switches (for fly-jibs) can be added. Connection is via the bullet-type connectors from the cable. When more than one ATB switch is required (e.g. main & fly), connect the ATB cables of the switches in series via the bullet-type connectors.


Hang the bob weight assembly from the switch eye after cutting the chain to length if desired to suit winch line speed. Repeat the procedure if required for rooster or fly jib.

Drawing References:

DWG 2934 – “Dimensional Detail, BB5 Anti-Two-Block Switch”

DWG 0667 (Sheets 1-2 of 3) – “ATB Switch Installation Details, Telescopic Crane”

Please note that high tensile booms require proper welding procedure specifications. Obtain specialist assistance in these cases.



Model BB-5 anti-two-block (ATB) switch

Cabling (Boom Sensors)

Sensor cables should be fixed firmly to where they are installed and routed along the boom chords through to the crane cabin ensuring freedom of movement around the boom pivot pin.

The cables are normally quite robust. They should be treated with care, however, as even a small amount of damage can be very costly due to downtime or intermittent behaviour. Always support the cable in such a way that there is no "excessive" strain applied, such as tension or flexing. The cable should be strapped to a fixed member that it runs along, unless it is held within a cable tray or trunking. Clip cables at approximately 600mm intervals or where suitable to secure them firmly to the boom. Avoid sharp bends such as around a sharp corner. Where there is to be flexing, the installer must ensure that the bending is reduced to an absolute minimum to avoid fatigue breakage of the conductors.

Drawing Reference:

DWG 1224 – “RCI Series Cable Connections”

Connectors

It is recommended that the installer applies a suitable silicone grease (e.g., Dow Corning 4 “Electrical Insulating Compound” or any similar compound) on the plugs and sockets prior to connecting the cables. The silicone grease should be smeared across the connector contact points to increase the water proofing of the connector.

INSTALLING CABIN PARTS

Display Unit and Key Switch Box

Fit the RCI-1502 Display Unit and Key Switch Box in a convenient position in the crane cabin such that the operator can view the displays and reach the push buttons comfortably.

Connect the Switch Box power supply lead to the key start switch or directly to the battery via a relay that is energised by the key start switch. Ensure that the polarity of the power supply is correctly connected.

Standard back plate bracket and kit comprising of bolts and nuts are provided. Special bracket may need to be fabricated on site for suitable mounting in the cabin.

Connect the load, angle, and anti-two-block ATB cables to the display unit.

Note: If a good earth connection between the mounting bracket and the cabin cannot be guaranteed then the earthing wire attached to the base of the display must be used to properly earth the display. Failure to do so could result in a non-operational ATB signal and faults due to Radio Frequency Interference.

Drawing References:

DWG 0279 – “Dimensional Drawing, RCI-1502 Display”

DWG 2459 – “Dimensional Detail, RCI-1502 Switchbox”

DWG 3336 – “RCI-1502 Switchbox V2 Wiring Diagram”



Display unit and typical installation inside the cabin

WIRING SLEW SWITCH/ES AND MOTION CUT OUTPUT

Slew/Proximity Switch/es (Optional Items)

The slew switch is used when the crane has different zones of SWL (e.g. over-rear ratings, over-side ratings, etc.). The switch will convey a signal to the display when the crane moves into a zone of different capacity rating. The RCI-1502 system can interface with up to three switches maximum.

The switch is magnetically switched and requires a metal target to switch ON. Fabricate, fix and secure a suitable mounting plate to the switch between the two locknuts supplied. Mount the plate/switch assembly at a suitable location on the revolving upperstructure preferably so that the switch moves and rotates with the upperstructure. The metal target plate must be mounted at a safe and suitable location on the carrier about which the upperstructure rotates.

Alternatively, fix the switch and target plate around the centre post of the crane slew (refer to typical installation photo below).

The gap between the switch and target must not exceed 10mm. The switch distance can be adjusted via the locknuts.

Connect the switch to the RCI-1502 Switchbox as per DWG 3336 (refer to Section 8.2. "Drawings" for details).

Drawing References:

DWG 2461 – "Dimensional Details, Proximity Switch (SWIPROX02)"

DWG 2462 – "Dimensional Details, Proximity Switch (SWIPROX03)"

DWG 930050 – "RCI Slew Switch Mounting"



Typical installation of slew/proximity switch

Motion Cut Output

The standard RCI-1502 Switchbox has an in-built relay to output the motion-cut signal. This allows connection of the crane's lockout solenoids direct into the Switchbox.

The Switchbox is fitted with a standard 24VDC (contact rating of 10A) relay when supplied from the factory. A spare 12VDC (contact rating of 10A) relay is also supplied with the installation kit supplied with the system. This is to replace the 24VDC relay if the crane's nominal supply is 12VDC.

To wire the crane's lockout solenoids, open the RCI-1502 Switchbox and use the following relay connections to match the solenoids:

<u>Relay Terminal No.</u>	<u>Contact Output Description</u>	
3	Normally	Open
4	Common	
5	Normally	Closed

The lockout solenoids on cranes are normally energised when crane is in safe condition (no alarm) and are de-energised when a motion cut condition occurs. Use contact terminals 4 (com) and 5 (NC) of the motion cut relay to wire the supply coil of the lockout solenoids. During motion cut activation, the motion cut relay is de-energised. This opens the relay contacts and also de-energises the lockout solenoids.

The Switchbox has a spare gland for motion cut cable entry. Please note that the motion cut cable is not supplied with the RCI-1502 System as a standard component.

Drawing Reference:

DWG 3336 – “RCI-1502 Switchbox V2 Wiring Diagram”

5. Calibration

WARNING

Calibration by untrained personnel may result in corruption of sensitive calibration data. Therefore, entry into calibration routines should only be performed by trained personnel.

Entering Calibration Mode and Selecting Calibration Functions:

- Make sure that the correct duty number (crane configuration) and falls (parts of line) are selected,
- Insert the over-ride key switch into the RCI-1502 Switchbox and turn it on, make sure that the O/RIDE indicator on the front panel is lit,
- Press and hold the SETUP button for about 2 seconds,
- The TOP window should show F-xx, where xx is the last calibration function performed or 00 if this is the first time you entered calibration mode,
- Once calibration mode is entered use the UP/DOWN keys to ramp through the calibration functions,
- When the correct function code is shown in the TOP window press the ENTER button to select that function,
- To exit calibration mode either select F-00 or press the CANCEL key until the F-xx code is cleared from the TOP window.

Tools/Items Required for Calibration:

- An accurate angle finder for calibrating boom angle sensor,
- An accurate tape meter of at least 100 ft. long (30.5m) for verifying radius,
- Known test weight of at least 75% of the hoist rope single linepull for calibrating the heavy load,

Note: For twin winch cranes, two test weights may be required, one for each winch if different linepulls.

- Software configuration sheets and function codes list provided at the back of this manual.

Map of Calibration (Suggested Order):

1. Set date and time (F-32 to F-34).
2. Verify that raw counts stay within 33- 999 for full working range of all sensors (F-07, F-11, F-15, F-19). F-19 is only required for twin winch cranes.
3. Review all crane geometry against the supplied Crane Configuration settings for correctness (F-45 to F-53) – refer also to Section 8.4. “RCI System Crane Configuration Sheet / Duty Listing” at the rear of the manual for factory default settings.
4. Review all SWL % parameters against actual requirements (F-42 to F-44) and change if required – refer also to Section 8.4. “RCI System Crane Configuration Sheet / Duty Listing” at the rear of the manual for factory default settings.
5. Review the data logger recording points against actual requirements (F-61 to F-67) and change if required – refer also to Section 8.4. “RCI System Crane Configuration Sheet / Duty Listing” at the rear of the manual.
6. Check Metric/Imperial units switching and set to required unit of measure. Use function code (F-69) if single winch crane, or code (F-71) if twin winch crane. Refer to Section 5.2.38. for details.
7. Calibrate low & high boom angle (F-09, F-10).
8. View and check accuracy of the calibrated angle value in degrees on function code (F-08).
9. Calibrate short & long boom length (F-13, F-14).
10. View and check accuracy of the calibrated length value in metres or feet (whichever “unit” is selected on item #6 above) on function code (F-12).
11. Calibrate light and heavy main winch load (F-02, F-03).
12. View and check accuracy of the calibrated Main load value in tonnes or kips (whichever “unit” is selected on item #6 above) using function code (F-01).
13. Calibrate light and heavy aux. winch load (F-05, F-06) – if twin winch crane.
14. View and check accuracy of the calibrated Aux. load value in tonnes or kips (whichever “unit” is selected on item #6 above) using function code (F-04) – if twin winch crane.
15. Apply averaging of samples, if required, using function code (F-27). Default value is 0 and maximum setting is 25. Try different value settings to stabilise the load readout if necessary. Refer to Section 5.2.21. for details.
16. For Twin winch cranes, set the main & aux hook block allowance while lifting on either winch, if required, using function code (F-68, Main Hook Block Allowance) and (F-69, Aux Hook Block Allowance). Refer to Sections 5.2.35. and 5.2.36. for details.
17. Set the rigging SWL (or Boom Stowed SWL While Fully Retracted), if required, using function code (F-68) if single winch crane, or (F-70) if twin winch crane. Refer to Section 5.2.37. for details.

-
18. Perform laden boom radius correction, if required, using function code (F-29). Refer to Section 5.2.22. for details.
 19. Once satisfied with the calibration results, manually record (pen & paper) the calibration data using function code (F-40) and all settings mentioned above. Refer to Section 5.7. "Copying & Restoring Calibration Data Function" for details and procedures.

5.1. Verifying Operation of Sensors

Before you start calibrating the RCI-1502, you must make sure that the sensors are working correctly and their signals are reaching the RCI-1502.

The RCI-1502 'sees' the crane and its surroundings through sensors. The signals from these sensors are represented as numbers inside the RCI-1502. The range of possible numbers is 0 to 1023 for each sensor.

The RCI-1502 allows the user to view both the UNCALIBRATED or the CALIBRATED signal from a given sensor (*refer to the Function Code Listing at the rear of this manual*).

When viewing the UNCALIBRATED signal from a sensor, make sure the number displayed is less than 999 and is more than 32 as you work the sensor through its working range. This is the correct operating range. Also make sure that the numbers displayed in the window are changing in a nice, smooth manner. If you find that the number is too unstable (i.e. changes by more than 10), then you should check the connections to the RCI-1502 (refer to Section 6. "Troubleshooting").

If the signal is less than 32, suspect a short circuit somewhere on that input channel, e.g. the cable to the RCI-1502 has been crushed and has an internal short circuit in it. Moisture inside the plugs can look like short circuit too.

If the count displayed in the window is 1023, look for an open circuit on that input channel. e.g. disconnected lead.

If the sensors check out then you can continue on and start with the calibration procedure. If you find any problems, check the troubleshooting guide at the end of this manual or seek help from your nearest LSI-Robway distributor.

Please note that while in view mode, that is using either "VIEW UNCALIBRATED ..." or "VIEW CALIBRATED ..." functions, the ENTER key works as a toggle switch to turn that channel ON or OFF. This function allows the user to temporarily turn a sensor off if it is not needed. E.g. if you want to use the main winch only on a twin winch system; normally, if you have not connected the auxiliary sensor up, the RCI-1502 will report an error and activate motion cut. To prevent this you can press the ENTER key, while in "VIEW UNCALIBRATED TRANSDUCER 2 function", to turn the auxiliary channel off.

To turn a channel back on, you have to re-enter the same VIEW UNCALIBRATED... function and press the ENTER key again.

Remember that you must always end a view function by pressing the CANCEL key.

5.2. Configuring User Variables

LSI-Robway stores the load-charts, crane geometry, default alarm and motion control settings, default data logging parameters, fine-tuning settings, and other useful user variables in the memory of the RCI-1502 at the time of manufacture. As this information may vary from crane to crane, even if they are of the same model, the RCI-1502 allows the installer to change these variables on site. These user variables include dimensions such as slew-offset, maximum falls for main/aux winches, maximum line-pulls, sheave diameters, etc.

The actual values of these variables are printed on a configuration sheet (see Section 8.4. "RCI System Crane Configuration Sheet / Duty Listing" at the rear of the manual). A copy of this sheet is also supplied separately with the system.

To verify or change the current value of any of these user variables follow the procedure below:

- Enter calibration mode,
- Select the correct function code from the listing then using the UP/DOWN keys ramp to that function code and press ENTER,
- If you want to change the value use the UP/DOWN key to select the new value then press the ENTER key,
- If you only want to verify the current value press the CANCEL key when finished viewing,
- Now you should be back at the F-xx prompt and can continue on with the next operation.

Please note that the value of these variables is very important as they affect the safe operation of the RCI-1502 indicator. Therefore the values of the user variables must be checked and corrected if necessary before proceeding with further calibration or operation.

5.2.1. Exit Calibration Mode (F-00)

Use this function to exit Calibration Mode. Alternatively, exiting calibration mode can also be done by pressing CANCEL button when on a function code other than F-00. Ensure that dashes (---) are shown on the bottom window before pressing CANCEL button to exit.

5.2.2. View Calibrated Main Load (F-01)

The calibrated Main Winch load can be verified on normal operating mode (operator's screen). This function is used to view the main calibrated load while still in calibration mode. This is useful when just verifying accuracy of the load readout and the calibration has not yet been finalised.

5.2.3. Calibrate Light Main Load (F-02)

Please see Section 5.5.1. "Calibrating Light Main Load" for details.

5.2.4. Calibrate Heavy Main Load (F-03)

Please see Section 5.5.2. “Calibrating Heavy Main Load” for details.

5.2.5. View Calibrated Aux Load (F-04) – For Twin Winch Cranes Only

The calibrated Aux Winch load can be verified on normal operating mode (operator’s screen). This function is used to view the aux calibrated load while still in calibration mode. This is useful when just verifying accuracy of the load readout and the calibration has not yet been finalised.

5.2.6. Calibrate Light Aux Load (F-05) – For Twin Winch Cranes Only

Please see Section 5.6.1. “Calibrating Light Aux Load” for details.

5.2.7. Calibrate Heavy Aux Load (F-06) – For Twin Winch Cranes Only

Please see Section 5.6.2. “Calibrating Heavy Aux Load” for details.

5.2.8. View Uncalibrated Angle Input (F-07)

Use this function to view the raw counts (or raw data) of the angle sensor. Please also Section 5.1. “Verifying Operation of Sensors” for details.

5.2.9. View Calibrated Angle Input (F-08)

The calibrated angle can be verified on normal operating mode (operator’s screen). This function is used to view the calibrated angle (in degrees) while still in calibration mode. This is useful when just verifying accuracy of the angle readout and the calibration has not yet been finalised.

5.2.10. Calibrate Low Angle (F-09)

Please see Section 5.3.1. “Calibrating Low Boom Angle” for details.

5.2.11. Calibrate High Angle (F-10)

Please see Section 5.3.2. “Calibrating High Boom Angle” for details.

5.2.12. View Uncalibrated Boom Length Input (F-11)

Use this function to view the raw counts (or raw data) of the length sensor. Please also Section 5.1. “Verifying Operation of Sensors” for details.

5.2.13. View Calibrated Boom Length Input (F-12)

The calibrated length can be verified on normal operating mode (operator's screen). This function is used to view the calibrated length (in metres or feet) while still in calibration mode. This is useful when just verifying accuracy of the boom length readout and the calibration has not yet been finalised.

5.2.14. Calibrate Short Boom Length (F-13)

Please see Section 5.4.1. "Calibrating Short Boom Length" for details.

5.2.15. Calibrate Long Boom Length (F-14)

Please see Section 5.4.2. "Calibrating Long Boom Length" for details.

5.2.16. View Uncalibrated Transducer 1 Input (F-15)

Use this function to view the raw counts (or raw data) of the Main Load transducer (main load sensor). Please also see Section 5.1. "Verifying Operation of Sensors" for details.

5.2.17. Function Codes (F-16 to F-18) – Not Used

These function codes are used for Load Moment-based systems only.

5.2.18. View Uncalibrated Transducer 2 Input (F-19) – For Twin Winch Cranes Only

Use this function to view the raw counts (or raw data) of the Aux Load transducer (aux load sensor). Please also see Section 5.1. "Verifying Operation of Sensors" for details.

Please refer to Section 8.3. "Function Codes" at the rear of this manual for the applicable set of codes. Two sets of codes have been provided in Section 8.3. One is for Single Winch cranes and the other is for Twin Winch cranes.

5.2.19. Function Codes (F-20 to F-22) – Not Used

These function codes are used for Load Moment-based systems only.

5.2.20. Function Codes (F-23 to F-26) – Not Used

These function codes are used for model RCI-4000IS System only.

5.2.21. Number of Sensor Samples to Average (F-27)

This function is used to stabilise the display in the event that the numbers (readouts during normal operating mode) are changing erratically. Function code F-27 will show the number of samples currently being used to average the sensor inputs. This value can be edited by using the Up/Down buttons. Default setting is "0" and the maximum selectable value is "25". Try different settings until the readouts are stable.

5.2.22. Perform Laden Boom Radius Correction (F-29)

This function code allows the installer to calibrate the system to account for laden boom deflection. As such it should only be used when the displayed load radius is less than the true operating radius of the crane. In such a case the installer should measure the physical load radius at a position where boom deflection is seen to have the maximum effect on the load radius.

Maximum boom deflection occurs when the boom is fully telescoped and a load, which approaches the SWL, is suspended on the hook. On duties where the winches are both assumed to be reeved over the main boom head it is necessary to calibrate only for the main winch. However, when a jib is installed it is possible to calibrate boom deflection both for the main boom head and for the head of the jib.

Laden Radius is provided for telescopic boom cranes to compensate for boom curvature (flexing) under laden conditions.

This should only be performed with fully extended boom at high angle (above 60 degrees) with at least 70% of the appropriate SWL lifted.

Activate this function code and change the displayed value to the actual measured distance from the crane slew centre-line to the hook with the load freely suspended.

5.2.23. Load Chart View Mode (F-30)

This function code can be used to view the load charts programmed in the software. It is not part of the calibration or set-up procedures. It is mainly used by LSI-Robway for software checking.

5.2.24. View Digital Inputs (F-31)

This function code is used to view the state (i.e. open or closed) of the three digital inputs (A, B, & C) on the RCI-1502. The inputs are used for wiring the slew/proximity switches if the crane has different zones of SWL. This function is useful when troubleshooting the input signals from the switches to the display, i.e. if the value changes when the switches are switched on and off. The values are as follows:

Digital Input: C-AB (Note: The I/O state of input C is different from A & B)

0-11	All switches (A, B, & C) open
0-01	A closed, B & C open
0-10	B closed, A & C open
1-11	C closed, A & B open
0-00	A & B closed, C open

5.2.25. Set Year (F-32)

Use this function to set the current year.

5.2.26. Set Day and Month (F-33)

Use this function to set the current day and month.

5.2.27. Set Time (F-34)

Use this function to set the current time. The time displayed is in the format HH:MM. An invalid time will cause an error message to appear. The seconds can't be edited and will always be "00" (hidden). The seconds will begin incrementing once the OK button is pressed.

5.2.28. Download Logger Contents to PC (F-35)

Please see Section 8.1. "Data Logging on RCI Systems" at the rear of the manual for details.

5.2.29. Erase Logger Contents (F-36)

Please see Section 8.1. "Data Logging on LSI-Robway RCI's" at the rear of the manual for details.

5.2.30. Alter Calibration Data (F-40)

This function is used for manually copying and restoring the calibration data which must be done after completing the system calibration. Please see Section 5.7. "Copying & Restoring Calibration Data Function" for details and procedures.

5.2.31. Clear All Calibration Data (F-41) – USE EXTREME CAUTION!

Activating this function will clear all the calibration data. This must only be used by LSI-Robway-trained personnel for troubleshooting purposes.

The display will prompt the operator to press ENTER if he wishes to erase the calibration data. Pressing ENTER here will clean out the memory system and default back to hard coded software. Any on-site changes made will be lost.

5.2.32. User Variables (SWL % Alarms, Motion Cut)

Function codes **(F-42 to F-44)** are used to set the Safe Working Load (SWL) percentages for activating Visual and Audible Alarms as well as the Motion Cut control output. The preset or factory default values are based on standard safe parameter settings and may be used. These values can be edited and changed using these function codes to suit requirements.

5.2.33. User Variables (Crane Geometry)

Function codes **(F-45 to F-53)** are used to set the actual physical dimensions (geometry) of the crane.

The factory default values are based on details and information received at the time of order and supply of system. Any changes to geometry will also require changing of these values using these function codes.

5.2.34. User Variables (Data Logging Setup Parameters)

Function codes (**F-61 to F-67**) are user variables relating to the setup parameters of the internal data logger. Please see also Section 8.1. "Data Logging on RCI Systems" at the rear of the manual for details.

5.2.35. Main Hook Block Allowance While Lifting on Aux Winch (F-68) – For Twin Winch Cranes Only

Normally, the system goes on alarm when either the Main or Aux winch has reached its maximum radius. On some cranes, the Aux winch may be used to operate up to its maximum radius limit even when the Main winch has already reached its maximum radius. To allow the Aux winch to operate this way, enter the weight of the Main hook block to this function code.

Please refer to Section 8.3. "Function Codes" at the rear of this manual for the applicable set of codes. Two sets of codes have been provided in Section 8.3. One is for Single Winch cranes and the other is for Twin Winch cranes.

5.2.36. Auxiliary Hook Block Allowance While Lifting on Main Winch (F-69) – For Twin Winch Cranes Only

Similar to Section 5.2.35. above, the Main winch may be used to operate up to its maximum radius limit even when the Aux winch has already reached its maximum radius. To allow the Main winch to operate this way, enter the weight of the Aux hook block to this function code.

Please refer to Section 8.3. "Function Codes" at the rear of this manual for the applicable set of codes. Two sets of codes have been provided in Section 8.3. One is for Single Winch cranes and the other is for Twin Winch cranes.

5.2.37. Boom Stowed SWL While Fully Retracted: (F-68) – Single Winch Cranes (F-70) – Twin Winch Cranes

This function is used to set a rigging SWL value for the crane and the boom to get past the maximum radius without activating the alarms. The value set must not exceed the weight of the Main hook block. When this function is used, the crane will assume a SWL equal to the weight of the hook block; thus, allowing the boom to go further down to the ground for rigging purposes without alarms as long as no load is lifted on the Main block.

Please refer to Section 8.3. "Function Codes" at the rear of this manual for the applicable set of codes. Two sets of codes have been provided in Section 8.3. One is for Single Winch cranes and the other is for Twin Winch cranes.

5.2.38. Metric/Imperial Units Switching: (F-69) – For Single Winch Cranes (F-71) – For Twin Winch Cranes

Use this function to select the required unit of measure (Metric or Imperial). Factory default setting is "Metric".

Press the ENTER button while in this function code to toggle between Metric ("S I" shown on display) and Imperial ("Lbs" shown on display).

Please refer to Section 8.3. "Function Codes " at the rear of this manual for the applicable set of codes. Two sets of codes have been provided in Section 8.3. One is for Single Winch cranes and the other is for Twin Winch cranes.

5.3. Calibrating Main Boom Angle

5.3.1. Calibrating Low Boom Angle

- Safely luff the boom down to a low angle, e.g. 30°,
- Enter calibration mode, if not already activated, and select the correct function code (F-09) for calibrating low boom angle,
- Accurately measure the actual boom angle using an angle finder,
- Use the UP/DOWN keys to ramp the display to the required value then press ENTER to accept this value.

5.3.2. Calibrating High Boom Angle

- Safely luff the boom up to a high angle, e.g. 65°,
- Enter calibration mode, if not already activated, and select the correct function code (F-10) for calibrating high boom angle,
- Accurately measure the actual boom angle using an angle finder,
- Use the UP/DOWN keys to ramp the display to the required value then press ENTER to accept this value.

Verify that the boom angle is accurately measured by using function code (F-08) VIEW BOOM ANGLE. Luff the boom and stop on different boom angle points. Check boom angle with the Angle Finder and verify accuracy against the displayed angle.

5.4. Calibrating Main Boom Length

5.4.1. Calibrating Short Boom Length

- Retract the main boom fully,
- Enter calibration mode, if not already activated, and select the correct function code (F-13) for calibrating short boom length,
- Refer to the crane manufacturer's load chart and verify fully retracted main boom length,
- Use the UP/DOWN keys to ramp the display to the required value then press ENTER to accept this value.

5.4.2. Calibrating Long Boom Length

- Extend the main boom fully,
- Enter calibration mode, if not already activated, and select the correct function code (F-14) for calibrating long boom length,
- Refer to the crane manufacturer's load chart and verify fully extended main boom length,
- Use the UP/DOWN keys to ramp the display to the required value then press ENTER to accept this value.

Verify that the boom length is accurately measured by using function code (F-12) VIEW CALIBRATED BOOM LENGTH INPUT. Fully retract and fully extend the boom and check the displayed length readings on both fully retracted and fully extended boom against the crane load chart values.

5.5. Calibrating Load on the MAIN Winch

5.5.1. Calibrating Light Main Load

- Safely lift a light, known test load off the ground, the load should be heavy enough to produce approximately 10% of the maximum single linepull of the main winch (or if not available, just lift the empty main hook block),
- Enter calibration mode, if not already activated, and select the correct function code (F-02) for calibrating a light load on the main winch,
- Use the UP/DOWN keys to ramp the display to the required value, i.e. the total weight of the light load lifted (or if not available, the weight of the empty main hook block),
- Press ENTER to accept value. Proceed to next Section 5.5.2. "Calibrating Heavy Main Load".

5.5.2. Calibrating Heavy Main Load

- Safely lift a heavy, known test load off the ground, the load should be heavy enough to produce approximately 75% of the maximum single linepull of the main winch,
- Enter calibration mode, if not already activated, and select the correct function code (F-03) for calibrating a heavy load on the main winch,
- Use the UP/DOWN keys to ramp the display to the required value, i.e. the total weight of the heavy load lifted (including the weight of the main hook block and all rigging accessories used),
- Press ENTER to accept value. For Twin Winch cranes, proceed to Section 5.6. "Calibrating Load on the Aux Winch".

Verify that the MAIN LOAD is accurately measured, using the VIEW CALIBRATED MAIN LOAD (F-01) function.

5.6. Calibrating Load on the AUX Winch – For Twin Winch Cranes Only

5.6.1. Calibrating Light Aux Load

- Safely lift a light, known test load off the ground, the load should be heavy enough to produce approximately 10% of the maximum single linepull of the aux winch (or if not available, just lift the empty aux hook block),
- Enter calibration mode, if not already activated, and select the correct function code (F-05) for calibrating a light load on the aux. winch,
- Use the UP/DOWN keys to ramp the display to the required value, i.e. the total weight of the light load lifted (or if not available, the weight of the empty aux hook block),
- Press ENTER to accept value. Proceed to next section 5.6.2. “Calibrating Heavy Aux Load”.

5.6.2. Calibrating Heavy Aux Load

- Safely lift a heavy, known test load off the ground, the load should be heavy enough to produce approximately 75% of the maximum single linepull of the aux winch,
- Enter calibration mode and select the correct function code (F-06) for calibrating a heavy load on the aux winch,
- Use the UP/DOWN keys to ramp the display to the required value, i.e. the total weight of the heavy load lifted (including the weight of the aux hook block and all rigging accessories used),
- Press ENTER to accept value.


Verify that the AUX LOAD is accurately measured, using the VIEW CALIBRATED AUX LOAD (F-04) function.

5.7. Copying and Restoring Calibration Data Function

The latest software for the mode I RCI-1502 features a facility to easily VIEW, COPY, and RESTORE Calibration Data by using function code **F-40** “Alter Calibration Data”.


Procedures in Recording/Copying Calibration Data:

1. Access Calibration Mode.
2. Activate function code **F-40 (Alter Calibration Data)**.
3. Press ENTER button to select and access the Alter Calibration functions.
4. Function **An1 (Angle Channel)** will be displayed on top window. An1 is the default item that comes up whenever F-40 (Alter Calibration Data) is activated.
5. The calibrated value of Angle will be shown on bottom window (e.g., 80.5° as shown in this example).




6. Use the Up/Down Arrow keys to go through all the following items listed below.


<u>Codes</u>	<u>Description</u>
An1	Angle
Ln1	Boom Length
rd1	Radius
tr1	Transducer 1
ld1u	Load 1 (or Main Load) Up
ld1d	Load 1 (or Main Load) Down
tr2	Transducer 2
ld2u	Load 2 (or Aux Load) Up
ld2d	Load 2 (or Aux Load) Down



7. Only the “highlighted” items above must be copied (note: “ld2d” is the Aux loadcell channel and must only be copied if the Aux Winch is used). To copy an item, select the item and press the ENTER key.




- In the example above, the default item **An1** has been selected.




- Press ENTER key while on the selected item (e.g. An1) to activate the Edit Codes. There are four (4) Edit Codes as follows:

Edit Codes Description

Edit Codes	Description
Lo_r	Raw Counts of Calibrated Data (Low End)
Lo_c	Calibrated Data (Low End)
Hi_r	Raw Counts of Calibrated Data (High End)
Hi_c	Calibrated Data (High End)




- The first Edit Code is **Lo_r** which refers to the **raw counts or raw data of the calibrated low angle** (e.g., 12 8 counts as shown in this example).



- Manually record/copy (with pen & paper) the **Lo_r** value.
- Use the Up/Down Arrow keys to go through and copy the rest of the edit codes (**Lo_c**, **Hi_r**, and **Hi_c**).


- Press CANCEL key to return to the item **An1** screen.
- Select the next item, **ld1d**, and repeat above procedures 6 to 13. Select and repeat the same on **ld2d** if Aux Winch is used (i.e. if crane is Twin Winch).



15. Ensure that the Edit Codes for the following items have been recorded/copied before exiting Calibration Mode:


An1
Ln1
ld1d
ld2d (if Aux Winch is used)

16. Keep the record for future use (e.g. to re-calibrate the system when calibration data is lost due to faults, or when the Eprom software chip or Dallas memory chip has been replaced with a new one).




Procedures in Editing & Restoring Calibration Data:

1. Access Calibration Mode.
2. Activate function code **F-40 (Alter Calibration Data)**.
3. Press ENTER button to select and access the Alter Calibration functions.




4. Function **An1 (Angle Channel)** will be displayed on top window. **An1** is the default item that comes up whenever F-40 (Alter Calibration Data) is activated.
5. The calibrated value of Angle will be shown on bottom window (e.g., 80.5° as shown in this example).




6. Use the Up/Down Arrow keys to go through all the following items listed below:

<u>Codes</u>	<u>Description</u>
An1	Angle
Ln1	Boom Length
rd1	Radius
tr1	Transducer 1
ld1u	Load 1 (or Main Load) Up
ld1d	Load 1 (or Main Load) Down
tr2	Transducer 2
ld2u	Load 2 (or Aux Load) Up
ld2d	Load 2 (or Aux Load) Down



7. Only the "highlighted" items above must be restored (note: "ld 2d" must only be restored if the Aux Winch is used). To restore an item, select the item and press the ENTER key.
8. In the example shown, the default item **An1** has been selected. Press the ENTER key while on the selected item (e.g. An1) to activate the Edit Codes.




- Use the Up/Down Arrow keys to go through the list of the four (4) Edit Codes as follows:


Edit

Codes Description

Lo_r	Raw Counts of Calibrated Data (Low End)
Lo_c	Calibrated Data (Low End)
Hi_r	Raw Counts of Calibrated Data (High End)
Hi_c	Calibrated Data (High End)




- The first Edit Code is **Lo_r** which refers to the **raw counts or raw data of the calibrated low angle** (e.g., 12 8 counts as shown in this example).




- Press the ENTER key to access edit mode (i.e. the word "EDIT" comes up on the top window, or centre window if the system is an RCI-4000).


- Use the Up/Down Arrow keys to change the **Lo_r** value with the previously copied data.




- Press the ENTER key to store this new value to **Lo_r** (e.g. from 12 8 to 10 9 as shown in this example).



14. The screen will then return to the **Lo_r** Edit Code screen.
15. Select the next Edit Code and repeat procedures 9 to 15 until all Edit Codes have been edited (i.e. calibration data have been restored).



16. Once all of the Edit Codes for **An1** have been edited, press the CANCEL key to return to the **An1** screen.
17. Repeat procedures 6 to 16 until all of the items have been edited.
18. Ensure that all of the following items have been edited before exiting Calibration Mode:



An1
Ln1
ld1d
ld2d (if Aux Winch is used)

6. Troubleshooting

The RCI-1502 system incorporates a number of software features that are designed to help the service person quickly identify a fault, **however** it must be stressed that these features cannot identify everything. They can only be used as a guide to identify additional checks that can be made. Some notes are provided below, followed by some example faults and possible causes.

1. **Identify the symptoms.** Take time to find out exactly what is happening to indicate a problem. If possible have the problem demonstrated so you can "describe it in your own words". Sometimes what someone else has told you is only part of the story.
2. **Leave the calibration alone!** Too many times a re-calibration has been attempted in order to rectify a problem before that problem has been correctly identified. This leads to added confusion as the perspective is generally moved from the real fault to "calibration problems". We have often received a message indicating that our display has "not accepted the calibration data". Most times this is due to a fault in a cable or sensor which was not identified prior to re-calibration. Re-calibration must only be performed when all physical inputs have been verified for correct operation, and in actual fact is rarely ever needed.
3. **Do you have your simulator with you?** A simulator is a very quick way to verify if the fault is external to the display and will save you a lot of heartache.
4. **Have you read the manual?** When all else fails, read the manual! Your answer may actually be in there.
5. **Know what information you need to gather.** If you collect the correct information from the display the job is half done. Before you begin to suspect faults with the system, you must satisfy yourself that the display is correctly configured for the crane environment. In other words, check that the correct duty, falls, slew zones etc. have been selected. Are all of the sensors connected? In general if sensors have been supplied with the system, they must always be connected. The display will check them continuously and issue an error if that sensor cannot be detected. Check your length, angle and radius against the chart to verify that the equipment is permitted to be in that situation. If there is still a problem once these have been checked, then you will need to check the hardware.
6. **The main pieces of useful information** obtainable from the displays are the **raw counts**. The raw count shows what the actual inputs are doing (i.e. like a signal strength indication). These raw counts are manipulated in software according to the calibration data stored in the display to produce the readouts on the Display Unit. If the calibration has been done incorrectly, or the configuration is incorrect, or something else is wrong, then the Display Unit readouts (e.g. the LOAD or ANGLE values) may provide you with misleading information.

YOU MUST USE THE "VIEW UNCALIBRATED...." FUNCTION CODES TO DETERMINE THE CORRECT OPERATION OF THE EXTERNAL SENSORS, NOT THE "CALIBRATED" VALUES. It should be noted here that for load related problems, the **"VIEW UNCALIBRATED TRANSDUCER"** function code must be used, and not **"VIEW CALIBRATED LOAD"**. For correct operation these values must be in the range 32 to 999. Anything outside of this range will produce an error. Refer to Section 5. "Calibration" on how to access these raw counts.

- 7. Check the obvious.** Once you have found a problem with a sensor for example, check all of the obvious things to do with that sensor such as making sure all of the connectors are tight. Be systematic - make notes about what you have done and what you found. You will find that under pressure you can easily forget what you have checked and it becomes very easy to miss things.

EXAMPLE PROBLEMS AND POSSIBLE CAUSES

Problems That Produce Error Codes:

Error code 101.

This is indicating that the signal from the angle sensor is too low or too high. This should be confirmed by viewing function code (F-07) "VIEW UNCALIBRATED ANGLE INPUT" and noting that the value shown on the LOAD LCD display is less than 33, or higher than 999.

Possible causes:

- Angle sensor incorrectly mounted. This is especially critical for the Electronic Angle Sensor. Refer to Section 4. "Installation" of the manual for installation of the angle sensor.
- The angle sensor signal wire is short-circuited to the shield or to the angle 0V.
- The angle sensor signal wire is shorted to the excitation positive wire.
- The angle sensor is not connected or there is an open circuit in either the angle sensor signal wire or the angle excitation positive wire.
- The angle sensor excitation voltage is shorted. If this is the case it will also affect the length and load channels.
- The angle sensor 0V wire is open circuit.

Error code 110.

This is indicating that the signal from the length sensor is too low or too high. This should be confirmed by viewing function code (F-11) "VIEW UNCALIBRATED BOOM LENGTH INPUT" and noting that the value shown on the LOAD LCD display is less than 33, or higher than 999.

Possible causes:

- The length potentiometer may not have been set up as per the manual. Refer to Section 4. "Installation" of the manual for installation of the angle sensor.
- The length sensor signal wire is short-circuited to the shield or to the length 0V.
- The length sensor signal wire is short-circuited to the excitation positive wire.
- The length sensor is not connected or there is an open circuit in either the length sensor signal wire, the length excitation positive wire, or the length 0V wire.
- The length sensor excitation voltage is shorted. If this is the case, it will also affect the angle and load channels.
- Payout cable may have broken.

Error code 201.

This is indicating that the signal from the main load sensor is too low or too high. This should be confirmed by viewing function code (F-1 5) "VIEW UNCALIBRATED TRANSDUCER 1 INPUT" and noting that the value shown on the LOAD LCD display is lower than 33, or higher than 999.

Possible causes:

- Load cell signal wires shorted together.
- The signal + is shorted to the shield.
- The excitation - is shorted to the shield.
- The excitation supply is shorted together. This will obviously affect all of the external sensors. Measure the excitation voltage and compare it with the expected value. If this is the cause, the UNCALIBRATED value will generally be non-zero, but below 33.
- The load cell is disconnected or there is an open circuit in one of the signal wires.
- The signal - is connected to the shield.
- The signal + and the excitation + are swapped.
- The signal - and the excitation - are swapped.

Error code 202.

This is indicating that the signal from the auxiliary load sensor is too low or too high. This should be confirmed by viewing function code (F-19) "VIEW UNCALIBRATED TRANSDUCER 2 INPUT" and noting that the value shown on the LOAD LCD display is lower than 33, or higher than 999.

Possible causes:

- Load cell signal wires shorted together.
- The signal + is shorted to the shield.
- The excitation - is shorted to the shield.
- The excitation supply is shorted together. This will obviously affect all of the external sensors. Measure the excitation voltage and compare it with the expected value. If this is the cause, the UNCALIBRATED value will generally be non-zero, but below 33.
- The load cell is disconnected or there is an open circuit in one of the signal wires.
- The signal - is connected to the shield.
- The signal + and the excitation + are swapped.
- The signal - and the excitation - are swapped.

Error code 240.

This is indicating that an overload has been detected. This error generally accompanies most other errors simply because most other errors will place the display into an overload condition. This being the case, you need to check what other errors are present and correct them first. Once these have been addressed the E240 error generally takes care of itself. The exception is of course, when the equipment has been put into a genuine overload situation which has not been caused by any external faults.

Possible causes:

- A genuine overload condition exists.
- There is a load on the auxiliary winch in a duty that does not allow anything on that winch.
- It has been caused by another Error code condition.

Error code 280.

This is indicating that the rated line pull has been exceeded.

Possible causes:

- A genuine line pull error exists.
- The number of falls selected is incorrect for the load being lifted, or does not match the actual falls reeved.

Error code 301.

This is indicating that the angle being measured is outside of its allowed range.

Possible causes:

- A genuine violation of the angle limits has occurred.
- The angle sensor mounting may have loosened allowing the sensor to move.
- Wrong duty selected.
- Check the angle displayed against the actual angle of the boom.

Error code 302

This is indicating that the length being measured is outside of its allowed range.

Possible causes:

- A genuine violation of the length limits has occurred.
- The length potentiometer mounting may have loosened allowing the sensor to move.
- Wrong duty selected.
- Check the length displayed against the actual boom length.
- Payout cable may have fallen off the reeling drum.
- Payout cable may have been broken or become tangled.

Error code 304.

This is indicating that the radius being measured is outside of its allowed range.

Possible causes:

- A genuine violation of the radius limits has occurred.
- Wrong duty selected.
- Check as per Error code 301 and 302.

Problems That Do Not Produce Error Codes:

The load does not vary when I lift a weight.

The load cable and/or the load sensor is/are faulty. Check the load cable for faults. If cable is good, check the resistance values of the load cell. This, however, does not give the complete story. Even if the resistances are correct, there is still a chance that a fault on the sensor exists. Replace the load cell.

The load display is very erratic and displays massive changes in value.

Check the view UNCALIBRATED TRANSDUCER INPUT for that channel. If the values are flickering by 2-3 counts while the display is changing by say a number of tonnes, then the cause is most probably calibration. One common cause of this is if different load values were entered for the high and low calibration without the actual load being altered (or of course there was an error in a load channel while you were calibrating). In other words you forgot to lift the heavy load! (It happens often) In this situation the display is confused because the calibration data is telling it that the signal it is seeing represents both the low load value and the high load value simultaneously. Correct the calibration.

This can also occur if only part of the calibration procedure has been completed. You should expect strange results if you have not completed the calibration of that sensor.

When the system starts in the morning the displays are erratic, but settle during the day.

This is a common sign of moisture ingress into either the display, the connectors, the sensors or the cable. These should be checked, dried and sealed.

The display does not start.

You should check the power supply. The RCI-1502 has a voltage range of 10 – 40 vdc. If the supply is within range, open the Switchbox and check the fuses.

The unit is on alarm, but no error code on display.

- Check for Two blocking condition.
- If no Two Blocking condition exist but the ATB LED on display is ON, check the “earth lead” from the display for proper grounding to crane chassis.
- If “earth lead” is OK, check the ATB switch and cable for faults.

On start-up the display shows “LCtrl” on top screen and then hangs (boot up not completed).

- This is a data logger control error. It happens when the internal data logger has been corrupted; when an upgraded or new software has been installed ; or when the memory chip (Dallas IC) has been replaced with a new one.
- To fix this error, insert and turn the override (by pass) key ON, then press the ENTER button. The display will show “YES” to confirm. While “YES” is shown on the screen, press the ENTER button again until the display gets into the normal initialisation/ set-up routine and then to normal operating mode.

7. Electrical Specifications

Power Supply Input (VDC)

Range: 10 VDC - 40 VDC

Power Consumption

< 1 amp (in full alarm)

Temperature Range

Operating: -20°C to +70°C

Digital Inputs

Total of three (3) digital inputs for connecting slew/proximity switches for monitoring different zones of operation, and/or for connecting other types of switches for any special crane requirement/application. Refer to Section 4. "Installation" of the manual for application details.

Motion Cut Relay Output

One (1) standard motion cut relay output available for wiring to crane lockout solenoids to inhibit crane motion when on overload/alarm condition. The relay fitted in the Switchbox is rated 10A @ 30 VDC. A spare 12 VDC relay is also supplied with the installation kit for use on 12 VDC cranes. Refer to Section 4. "Installation" of the manual for application details.

Sensors

Load Sensor/s

Capacity:	Various capacities to suit application	
Excitation Voltage:	4.0 VDC regulated (provided by the Display unit)	
Linearity :	0.15% nominal	
Repeatability:	> 0.10%	
Hysteresis:	< 0.10%	
Creep:	< 0.10%	
Output:	1, 2, or 3 mV/V nominal	
Isolation:	> 2000 MOhms at 50 VDC	
Overload:	150% (no electrical damage) > 400% (ultimate)	
Temperature Effects:		
On Zero:	< 0.006% / °C	
On Span:	< 0.005% / °C	
Compensated Range:	-10°C to +70°C	
Sealing:	IP68 fully encapsulated	
Pin/Wire Connections (5-Way Connector):		
Pin A	Black	Negative Excitation
Pin B	White	Negative Signal
Pin C	Red	Positive Excitation
Pin D	Green	Positive Signal
Pin E	Screen	Screen

Expected Resistances (for a standard 350-Ω cell):

Red - Black 300 - 600 Ω

Red - Green 200 - 400 Ω

Red - White 200 - 400 Ω

Black - Green 200 - 400 Ω

Black - White 200 - 400 Ω

White - Green 350 Ω ± 2 Ω

Shield/Screen to any other wire must be open circuit

Electronic Angle Sensor

Type: Capacitance-based sensor with no moving parts, ratiometric output

Excitation Voltage: 4.0 VDC regulated (provided by the Display unit)

Operating Range: +/- 45° (offset mounted to accommodate 0 - 90°)

Ac Accuracy: +/- 0.2°

Cable Entry: Mil-spec plug/socket connector (Angle Sensor & Length Sensor are joined in one cable and connector from the Recoil Drum)

Mounting: Via screws inside the Recoil Drum

Weight: 0.3 kg

Pin/Wire Connections (7-Way Connector, joined with Length Sensor):

Pin A	Red	Positive Excitation
Pin E	White	Angle Signal
Pin C	Black	Negative Excitation

Expected Resistances: High ohms or open circuit between any of the wires and chassis or shield

Boom Length Sensor

Type: 500-ohm 10-turn potentiometer

Excitation Voltage: 4.0 VDC regulated (provided by the Display unit)

Operating Range: 0-30 metres

Accuracy: +/- 0.05 metre

Cable Entry: Mil-spec plug/socket connector (Angle Sensor & Length Sensor are joined in one cable and connector from the Recoil Drum)

Mounting: Via screws inside the Recoil Drum

Weight: 0.1 kg

Pin/Wire Connections (7-Way Connector, joined with Angle Sensor):

Pin A	Red	Positive Excitation
Pin B	Blue	Length Signal
Pin C	Black	Negative Excitation

Expected Resistances: High ohms or open circuit between any of the wires and chassis or shield

Proximity Switch

Type: PNP – N.O. & N.C.

Sensing Range: 10 mm

Operating Voltage: 10 – 30 VDC

Switching Current: 200 mA maximum

Anti-Two-Block Switch (Model BB5)

Type:	V4 IP67 sealed, leaf
Contact Rating:	28 VDC/3A
Electrical Life:	10 ⁵ operations
Operating Force:	0.6 N (max)
Release Force:	0.08 N (min)

Cables

General:	2-, 4-, 6-, & 10-core braided, UV stabilised, PVC sheathed cables
DC Resistance:	38.2 ohms/km @ 20°C (25.45 ohms/km for 2-core cable)
Core Insulation:	V90-HT PVC (designed to comply to AS/NZ 3808:2000)
Electrical Life:	10 ⁵ operations
Cable Integrity:	All cores tested for insulation resistance @ test voltage of 500V
Sheath:	Overall 5V90 UV stabilised PVC
Current Rating:	3 amps
Capacitance:	150 pf/m (core to core)

8. Appendices

8.1. DATA LOGGING ON RCI SYSTEMS

8.2. DRAWINGS

8.3. FUNCTION CODES

8.4. RCI SYSTEM CRANE CONFIGURATION SHEET / DUTY LISTING

Appendix 8.1.
Data Logging on RCI Systems

Data Logging on RCI Systems

Introduction

The RCI System Logging occurs automatically whenever the driver lifts a load OR whenever the RCI System detects an error condition on the crane such as moving outside the load chart. The installer has the option to set the percentage of SWL a load must reach before the load will be logged. This *logging percentage* can be set anywhere between 13% and 110% of SWL.

In addition, the installer can configure three *lift counters* which can count the number of lifts performed in three distinct SWL % regions below the *logging percentage*.

Description of Logging Features

Data Logging is stored in a circular arrangement. That is, when the logs are full and another log is performed, the oldest log in the logger will be over-written. Each record stores the following data:

Date	Date log was recorded (dd/mm/yyyy)
Time	Time log was recorded (hh:mm)
Peak Load	Peak load recorded during log cycle
Stable Load	Maximum Stable load recorded during log cycle
Safe Working Load	SWL at operating position
Percent of SWL	Percentage of SWL
Radius Operating	Radius
Error Codes	4 digit <i>standard LSI-Robway Error Codes</i>
Duty Number	Selected Duty number
Winch selected	Selected winch
Falls reeved	Selected falls
Over-ride state	Off / On indicates whether display was in over-ride

Logging is performed automatically when the percentage of SWL exceeds a threshold value which is set in Function Codes.

When the *logging percentage* is not exceeded while lifting a particular load, the lift occurrence can still be recorded in a *lift counter*. Three separate *lift counters* can be configured to store the number of lifts which occur in a particular SWL % region. Once again, the exact SWL percentages which will be counted can be configured by setting the appropriate Function Codes.

Data Logging on RCI Systems

A summary of the logging percentage Function Codes is displayed in the following table:

Function Code Name	Description	Default Setting
Low Load Lift counter	swl percentage to record	20.0%
Medium Load Lift counter	swl percentage to record	40.0%
High Load Lift counter	swl percentage to record	65.0%
Logging Percentage	swl percentage to log	90.0%

These default settings would give rise to the following logging operation:

Low Load Lift Counter	counts the number of lifts which produce a SWL % which is greater than or equal to 20% but less than 40%.
Medium Load Lift Counter	counts the number of lifts which produce a SWL % which is greater than or equal to 40% but less than 65%.
High Load Lift Counter	counts the number of lifts which produce a SWL % which is greater than or equal to 65% but less than 90%.
Logger	Records full configuration data of any lift which produces a SWL % which is greater than or equal to 90%

Setting Up the Data Logger

Data logging will occur at all times the display is operational. This includes the cases when, the over-ride is activated, the display is reporting an error and during the initial calibration of the system.

For the Logger to operate properly the display must be fully and correctly calibrated. However, since the logger was recording during calibration it is probably desirable to erase the logger contents after completing the angle and load calibrations on the RCI System since the logger would have recorded some invalid information during the calibration of the sensors.

To erase the data logger contents, simply activate the appropriate Function Code once calibration is complete (refer to Function Codes list at the rear of the Manual for the appropriate code).

The operator can access three more Function Codes which control how the actual logging of loads operates. These three Function Codes are summarised in the following table

Stable Load Time	time during which load must stay stable in order to log
Stable Load Variation	load must stay within this variation to be considered stable
Reset Time	load must stay below the Low Load Counter threshold for this time before the log cycle ends

Data Logging on RCI Systems

The first two Function codes in the table are used for determination of a stable load. When a load is hoisted it is probable that the initial load reading will be greater than the actual load on the hook because of the "snatching effect". The stable load is recorded only when these dynamic factors have died down and the load can be considered to be hanging from the hook in a relatively motion free position.

The "Stable load time" and "Stable load variation" Function codes can be used to adjust the load recording to minimise the effect of dynamic factors. The load will be considered stable if the load reading does not change by more than the "Stable load variation" setting (which is 0.1t by default) for a period of time set by "Stable load time" (which is 2 seconds by default).

The third Function code, "Reset time," is used for terminating a lift. When the load causes a SWL % which is less than the logging values (specifically the Low Load Lift counter percentage), then it is assumed that the driver must be putting the load down again. In order to ensure that a single load is not logged multiple times because the SWL % was hovering around the logging threshold, a log cycle will not complete until the load SWL % remains below the threshold for a certain period of time, namely of course the "Reset time" (by default the reset time is set for 5 seconds).

Log Cycle Description

Two types of log cycles are possible:

1. Load is lifted inside load chart boundaries (valid SWL is seen at all times).
2. SWL drops to 0 indicating the load chart has been exceeded, sensor error has occurred or slew error has occurred.

Type 1 Log- Valid SWL cycle

A log cycle is started when:

- the current SWL % (load/swl) exceeds the THRESHOLD (which will be the value set for the Low Load Lift Counter function Code).

During a log cycle:

- the load is monitored, the peak load seen is continually updated and if no stable load has been recorded then all other data is recorded against peak load.
- a stable load condition will apply when the load remains within a small variation range (set by user through F-Code "Stable Load Variation") for a certain period of time (also an F-Code "Stable Load Time").
- when a stable load is seen, all data (except peak load) are recorded against the stable load.

Data Logging on RCI Systems

- load monitoring continues, the SWL percentage is continually checked against the SWL percentage which was stored, if the percentage increases, a new stable load will be recorded.

A log cycle is completed when:

- the current SWL % drops below the THRESHOLD for a period of time set by the Reset Time Function Code
OR
- the SWL drops to 0 initiating a Type 2 Log cycle.

In either case, the currently performed log will be stored prior to initiating a new cycle.

Type 2 Log- Out of Load Chart / Error conditions

A log cycle is started when:

- SWL drops to 0, implying SWL % is unknown but definitely greater than 110%. In this case the SWL is nominally set to 110% and appears as ">110%" in the logger print out.

During a log cycle:

- the load is monitored and the peak load seen is continually updated (in log 1).
- the radius is monitored and the max. radius seen is continually updated (in log 2).

A log cycle is completed when:

- SWL becomes > 0 (log 1 AND log 2 are stored and condition for starting a type 1 log is checked).

Hence, if a load is lifted within the load chart a single log is performed. If the boom is positioned outside of the load chart, any log cycle in progress is stored and a new cycle begins. During this overload cycle two individual logs will be performed. One log will record the maximum load reading which is observed and the other will record the maximum radius which is observed. It is necessary to perform two logs because it is impossible to know which is a more unsafe condition, a longer radius or a shorter radius but higher load on the hook.

Stable loads are not monitored during out-of-chart/error logging cycles.

Data Logging on RCI Systems

Example Load Lift

Suppose a driver lifts a load and luffs out. If we assume the SWL % generated at the edge of the load chart is sufficient to cause a log to record then as soon as the driver exceeds the maximum radius on the chart, the active log cycle completes and is written to the logger prior to beginning an "out-of-chart" log cycle.

The out-of-chart cycle continues until the driver luffs the crane back into a safe condition. As soon as the safe condition is achieved, the out-of-chart logs (one for max. load and one for max. radius) will be stored to the logger.

Because the crane is now back in a safe condition, a new logging cycle begins. When the driver finally puts this load down (assuming he does not luff off the chart again) the normal log cycle completes and another log is written to the logger.


Hence, although the driver has lifted only a single load and luffed it to several positions, the actual load has been recorded a total of 4 times. This example serves to illustrate that if the crane is continually working on its outer radius, the Logger will fill very quickly.

It should be noted that if motion cut is connected and the display is not in over-ride, luffing to the outer radius limits of the load chart could cause the crane to oscillate as motion cut activates. In this case many logs may be recorded.


Data Logging on RCI Systems

Example Lift Cycles


EXAMPLE 1: Smooth lifting of load




EXAMPLE 2: Grabbing a load



EXAMPLE 3: Partial lift (tension line) then lift load



EXAMPLE 4: Grab then drop or Crane Failure



Data Logging on RCI Systems

Accessing the Data Logger

When the RCI System is powered on the normal check routines are performed. If your display has logging enabled then the percentage of the logger which is full is displayed on start up in the LOAD window. The display will show the prompt "=LE=" if the logger is completely empty, otherwise the prompt "LXXX" will show where XXX is the percentage of the logger which is currently filled.

The operator can use two more Function codes for accessing the information stored in the data logger. These Function codes are used for:

Downloading the data logger records to a PC, and
Erasing the content of the data logger

Downloading Data Logger Information

Downloading of data logger records can be performed at any time by attaching the cable provided between the RCI System and a standard PC or laptop and selecting the "Download Log Data" Function Code (refer to Function Codes list at the rear of the Manual for the appropriate code).

Communication Settings

The download is performed as an ASCII file transfer which means any standard terminal emulator software (e.g. sim term, procom m, etc.) or the standard HyperTerminal program of Windows (98, XP, etc.) could be used to receive the information from the RCI System.

Communication Settings for the transfer are:

Baud Rate	= 9600
Data Bits	= 8
Parity	= none
Stop Bits	= 1

Data Logging on RCI Systems

Downloaded Data Format

Each record will be printed in chronological order followed by a summary on the contents of the data logger. If no records have been stored a message to this extent is displayed on the RCI calibration window however, the summary information is still downloaded to the PC.

The summary consists of 6 lines of information as follows:

1. DOWNLOAD PERFORMED (date time)
2. Percentages Changed (date time) ***
3. No. Lifts in range 20% to 40% SWL = xx
4. No. Lifts in range 40% to 65% SWL = xx
5. No. Lifts in range 65% to 90% SWL = xx
6. No. Lifts logged with > 90% SWL = xx

*** Note: Default date if percentages have not been altered from LSI-
Robway settings is 01/01/96.

The first line simply states the date and time of when the download was performed.

The second line shows the date and time of when the percentage values for the counters and/or the logging percentage were last changed. The default date displayed is the 01/01/96. If the percentages are changed, the new date and time will be stored. This date and time will be maintained until the values are once again altered or calibration data is cleared.

The third, fourth and fifth lines give counts of the total number of lifts performed in the specified regions of SWL %. The percentages shown in this table can of course be changed in Function codes (causing the date in the second line to change as just discussed).

The sixth line gives a count of the number of full logs which have been performed and printed.

The records are printed 1 per line with each field in the record separated by a tab character. This means the resultant file stored on the PC is a tab delimited text file which is a suitable format for importing into spreadsheet programs such as Microsoft Excel.

Generally spreadsheet programs will automatically recognise the file format as a tab de-limited text file and promptly convert the data into a spreadsheet format. In some cases it may prove necessary to ensure the file is saved with a .txt extension name which is the standard extension for ASCII text files.

Data Logging on RCI Systems

Downloading of the logger can be performed any number of times without affecting the contents of the logger. Generally however, after downloading is performed, it is normally desirable to erase the contents of the logger.

Downloading takes approximately 15 seconds per 100 records.

Erasing Data Logger Information

Erasing of data logger records can be performed at any time by accessing the Function Code for "Erasing Log Data" (refer to Function Codes list at the rear of the Manual for the appropriate code).

Erasing the data logger will cause all currently recorded logs to be erased (hence the information can no longer be downloaded) and it also clears the SWL % counters.

In effect, the logger is now empty, however, the old records in the data logger have not really been erased, simply the program log counters have been erased. Hence, in the event that the data logger has been erased but the information has not been saved it is possible to have the data extracted from the logger by sending the display to LSI-Robway for analysis.

Data Logging on RCI Systems

Errors in Logger Data

On powering the display the contents of the data logger is checked in three separate operations. In 99% of cases these checks will all pass OK. If however a check fails the state of the logger is immediately questionable. Where possible the operator is given the choice of erasing the suspect data, however, in some instances, the logger will automatically be erased.

If you observe an error and have the option to erase the logger contents, we recommend you don't immediately erase the logger if there is desired information stored there, but rather download the data before then erasing.

These errors should not occur except in extenuating circumstances. If you have trouble with log errors you should immediately report such errors to LSI-Robway along with the pertinent information about your display (display serial number & software number)

Firstly, the control structure for the data logger is checked. If an error is found in the control structure for any reason, then the display AUTOMATICALLY ERASES data logger contents (because future logging is not reliable). If this error occurs the message:

LOG CONTROL ERR!
RESETTING LOGGER

is displayed in the calibration window. The only way to retrieve any data in the logger in this case is to send the display to LSI-Robway for analysis.

Secondly, the actual data in the logger is checked for errors. In the case that the data is found to be suspect then the message:

LOG DATA ERROR!
<ENTER> to ERASE

is displayed in the calibration window. In this event the user is prompted as to whether to erase the logger contents. Ideally the data should be erased since it is not totally reliable however, the choice is presented so as to give the opportunity to download the information prior to erasing the data (note erasing the data also clears the lift counters).

Lastly, the lift counters are checked for errors. Once again, if an error is found the user has the choice of erasing the counts or ignoring the error.


LOG COUNT ERROR!
<ENTER> to ERASE

If the error is ignored, the count values cannot be relied upon as correct.

Appendix 8.2.

Drawings

SYSTEM CODES	REF. No.
SYS1502-12	SYS1502-12
SYS1502-13	SYS1502-13
SYS1502-15	SYS1502-15
SYS1502-16	SYS1502-16
SYS1502-17	SYS1502-17



NOTE: LEFT HAND MOUNT SHOWN FOR INDICATION PURPOSES ONLY.

SYSTEM NOTES:
PLEASE NOTE THERE ARE OPTIONAL ITEMS WHICH MAY BE SUPPLIED AS PART OF THE SYSTEM, THEY ARE AS FOLLOWS -

- 1) ANTI-TWO BLOCK (ATB) SWITCHES WITH BOB WEIGHTS AND CHAINS, NUMBER OF WHICH CAN VARY DEPENDING ON THE NUMBER OF WINCHES.
- 2) THE DYNAMOMETERS CAN BE FITTED ON WITH THE MAIN WINCH OR AUXILIARY WINCH, FOR SOME TWIN WINCH APPLICATIONS A "DOUBLE DYNO" MAY BE USED.
- 3) LOAD CABLES CAN VARY IN LENGTH DEPENDING ON THE APPLICATION.
- 4) PROXIMITY SWITCHES, 3 MAXIMUM.
- 5) SLIP RING ASSEMBLY FOR FIXED CABIN CRANES.
- 6) DATALOGGING FACILITIES.
- 7) WARNING LIGHT 24/12V.

* CONTACT ROBWAY OFFICE FOR FURTHER DETAILS *

- REPRESENTS OPTIONAL ITEMS (SEE NOTES)
- _____ REPRESENTS CUSTOMER SUPPLIED ITEMS

REV	DATE	DESCRIPTION OF CHANGE	APPR'D	DRAWN	APPROVED	PART OF ASSY	CUSTOMER:	PROJECT:
1.1	04/06/04	SYSTEM CODES ADDED	A.C.	S. CHAMBERS	A. CANLAS	-	RCI-1502 GENERAL ARRANGEMENT FOR	SCALE N/A
1.2	19/10/06	NEW SWITCHBOX (SWISB1502V2)	S.C.	12/07/01	12/07/01	-	TYPICAL TELESCOPIC BOOM HOIST ROPE	SHEET 1 OF 1
1.3	05/03/08	PCR#18 - REMOVE EXT. LIGHTS	S.C.				TENSION (HRT) SYSTEM	REV 1.4
1.4	09/02/2011	REFER TO PCR#380	L.L.					
							DRAWING No: 2464	FILE No: 246401AE.DWG

32 West Thebarton Rd
THEBARTON
SOUTH AUSTRALIA 5031
web : www.lfrobway.com.au
PH: +61 8 8238 3500
FX: +61 8 8352 1684




TOL: X: +/- 1
X.X +/- 0.2
X.XX AS STATED



DRAFTING STANDARD: AS1100

DO NOT SCALE DRAWING
ALL DIMENSIONS ARE IN MILLIMETERS
UNLESS OTHERWISE STATED

REV	DATE	DESCRIPTION OF CHANGE	APPR'D
1.1	04/06/04	SYSTEM CODES ADDED	A.C.
1.2	19/10/06	NEW SWITCHBOX (SWISB1502V2)	S.C.
1.3	05/03/08	PCR#18 - REMOVE EXT. LIGHTS	S.C.
1.4	09/02/2011	REFER TO PCR#380	L.L.



3RD ANGLE




4 X Ø7MM MOUNTING HOLES

REV	DATE	DESCRIPTION OF CHANGE	APP'R'D	DRAWN		APPROVED	PART OF ASSY	PART No:	PROJECT:	SCALE	
				S. CHAMBERS		A. CANLAS	-	-	RCI-1502 SWITCH BOX	N/A	
				10/07/01		10/07/01				SHEET	
										1 OF 1	
										REV	
										1.0	
				TOI: X +/- 1 XX +/- 0.2 XXX AS STATED				DO NOT SCALE DRAWING ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED		DRAWING No: DWG 2459 FILE No: 245901AA.DWG	

EXTERNAL WARNING LIGHT RELAYS
(RELAY 1, 2 & 3)
EXTERNAL ALARM RELAY
(RELAY 4)

NOTE: RELAYS (RELSVSPCO) ONLY INSTALLED
UPON CUSTOMER REQUEST

SHORTING PATCH FOR -
ENABLE EXTERNAL ALARM IN SERIES
WITH RED WARNING LIGHT (RL4)



10 CORE DISPLAY INTERFACE
CABLE

SUPPLY +VE (RED)
POWER - (BLACK)
OVERIDE (PINK)
INPUT B (ORANGE)
INPUT A (VIOLET)
MOTION CUT (YELLOW)
BUZZER (GREEN)
SPARE (BLUE)
SPARE (BROWN)

2 CORE CABLE
(VDC POWER INPUT)
(CABP1206)

24V RELAY IS INSTALLED AS STANDARD UNLESS
OTHERWISE SPECIFIED.
(12V RELAY SUPPLIED IN INSTALLATION KIT)

OVERIDE
KEYSWITCH
(SWIKA3368)

3.15A FUSE
(POWER)

SUPPLY +VE (RED)
SUPPLY -VE (BLACK)

MOTION CUT (N/C)
MOTION CUT (N/O)
MOTION CUT (COMMON)

EXTERNAL ALARM (N/O)
EXTERNAL ALARM (COMMON)

EXTERNAL WARNING LIGHT (RED)
EXTERNAL WARNING LIGHT (YELLOW)
EXTERNAL WARNING LIGHT (GREEN)
EXTERNAL WARNING LIGHT (COMMON)


SUPPLY +VE
INPUT C
INPUT B
INPUT A
SUPPLY -VE

EXTERNAL AUDIBLE ALARM

CUSTOMER WIRED
(UNLESS OTHERWISE
REQUESTED)

INSTALLATION NOTES:
1. THE MOTION CUT OPTION IS RATED FOR 10A 30V MAX. ENSURE THAT THE SOLENOID DOES NOT EXCEED THIS RATING.
2. THE INPUTS MARKED AS "A", "B", AND "C" ARE GENERAL PURPOSE INPUTS. THEIR FUNCTION ARE DEFINED IN THE SOFTWARE DESPATCHED FOR A PARTICULAR APPLICATION. REFER TO THE CONFIGURATION SHEET IN THE MANUAL FOR THEIR DEFINITION.
3. PREVIOUS DEFAULT DEFINITION FOR THE INPUTS WERE:
- INPUT "A": MAIN DIRECTION, CLOSED = DOWN.
- INPUT "B": AUXILIARY DIRECTION, CLOSED = DOWN.
- INPUT "C": SLEW SWITCH, GENERALLY OPEN PRODUCED A DE-RATING.
4. ALL SLEW SWITCHES MUST BE RATED AT 35V OR MORE TO AVOID DAMAGE TO THE SWITCH.

PROXIMITY SWITCH WIRING






REV	DATE	DESCRIPTION OF CHANGE	APPRVD	TOL: X: +/-1 X:X +/-0.2 X:XX +/-0.02	DRAWN BY S. CHAMBERS	APPROVED BY	PART OF ASSY	PART No: SWISB1502V2	PROJECT: 1502 SWITCHBOX (VERSION 2)	SCALE N/A
		DO NOT SCALE DRAWING ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED						TITLE: WIRING DETAIL		SHEET 1 OF 1
								DRAWING No: DWG 3336		REV 1.0
								FILE No: 333601AA.idw		

32 West Thebarton Rd
THEBARTON
SOUTH AUSTRALIA 5031
web : www.lsirobway.com.au
PHONE: +61 8 8238 3500
FAX: +61 8 8352 1684



©copyright robway 2005




BOTTOM VIEW
OF BRACKET

REV	DATE	DESCRIPTION OF CHANGE	APPR'D	TOL:	+	-	SCALE
1.0	09/11/00	CONVERTED TO AUTOCAD FORMAT	D.P.	X	+/-	1	N/A
				XX	+/-	0.2	
				X.XX	AS	STATED	

DO NOT SCALE DRAWING
UNLESS OTHERWISE STATED


DRAWN	APPROVED	PART OF ASSY	PROJECT:
M. OBST		-	RCI-1502 DISPLAY
07/06/94			

LSI ROBWAY		LSI-ROBWAY	
32 WEST THEBARTON RD		THEBARTON 5031	
SOUTH AUSTRALIA		PHONE +61 8 8352 6055	
FAX +61 8 8352 1684		DRAWING No: DWG 0279	
		FILE No: 027901AA.DWG	
		SHEET 1 OF 1	
		REV 1.0	




4 Core Payout cable
13m Extension

REV	DATE	DESCRIPTION OF CHANGE	APPRVID	TOL:	+	-	±	+	-	±	+	-	±	DRAWN BY	APPROVED BY	PART OF ASSY	PART No:	PROJECT:	DRAWING No:	FILE No:	SHEET	REV
				X	+/1			X	+/-0.2					J.Hart			DRUKOR0413LAB		4576	457601AA.idw	A4	1.0
DRAFTING STANDARD: AS1100 DO NOT SCALE DRAWING ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED																						
DRAUGHTING STANDARD: AS1100 DO NOT SCALE DRAWING ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED																						
LSI ROBWAY A Division of Load Systems International											32 West Thebarton Rd THEBARTON SOUTH AUSTRALIA 5031 web : www.lsirobway.com.au PHONE: +61 8 8238 3500 FAX: +61 8 8352 1684											
											Overall Dimensions and Mounting Centers											



Material; MILD STEEL
Finish; GOLD PASSIVATE

REV	DATE	DESCRIPTION OF CHANGE	APPRVD	TOL:	DRAWN BY	APPROVED BY	PART OF ASSY	PART No:	PROJECT:				
				X: +/-1 X.X +/-0.2 X.XX +/-0.02	Johnh 19/04/2013			PLAM4807					
				DRAFTING STANDARD: AS1100	 32 West Thebarton Rd THEBARTON SOUTH AUSTRALIA 5031 PHONE: +61 8 8238 3500 FAX: +61 8 8352 1684 www.lsirobway.com.au				TITLE:				
				DO NOT SCALE DRAWING ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED								MOUNTING PLATE TO SUIT RW10 TO DRUKOR0413	A4
												DRAWING No: 4807	SHEET 1 OF 1
										REV A			
										FILE No: 4807-A.idw			



420.0 for 26m drum
520.0 for 35m drum


390.0 for 26m drum
490.0 for 35m drum

4 Core Payout cable
26m Extension & 35m
Extension

DRUKOR0426LAB/DRUKOR0435LAB

REV	DATE	DESCRIPTION OF CHANGE	APPRVD	TOL:	X	+/-1	DO NOT SCALE DRAWING UNLESS OTHERWISE STATED	DRAWN BY	APPROVED BY	PART OF ASSY	PART No:	PROJECT:	A4			
				X.X	+/-0.2			J.CHOI					SHEET			
				X.XX	+/-0.02			19/01/2012					1 OF 1			
													REV			
													1.0			
				DRAFTING STANDARD: AS1100							32 West Thebarton Rd THEBARTON SOUTH AUSTRALIA 5031 web: www.lsirobway.com.au PHONE: +61 8 8238 3500 FAX: +61 8 8352 1684		DRAWING No: 4577 FILE No: 457701AA.idw		OVERAL SIZE & MOUNTING DETAILS	

**ELECTRONIC
ANGLE SENSOR**



REV	DATE	DESCRIPTION OF CHANGE	APPRVD	DRAWN BY	APPROVED BY	PART OF ASSY	PROJECT:
				J. CHOI	J. HART		DRUKOR0426LAB
				20/01/2012	31/01/2012		RECOIL DRUM
							TITLE:
							TOP ASSY, 2.6m RECOIL DRUM, LENGTH, ANGLE & 4 CORE PAYOUT CABLE
							PROJECT:
							RECOIL DRUM
							A4
							SHEET 6 OF 6
							REV 1.0
							DRAWING No: 4581
							FILE No: 458101AA.idw

32 West Thebarton Rd
THEBARTON
SOUTH AUSTRALIA 5031
web : www.isirobway.com.au
PHONE : +61 8 8238 3500
FAX : +61 8 8352 1684




TOL: X. +/-1
X.X +/-0.2
X.XX +/-0.02

DRAFTING STANDARD: AS1100

DO NOT SCALE DRAWING
ALL DIMENSIONS ARE IN MILLIMETERS
UNLESS OTHERWISE STATED

ELECTRONIC ANGLE SENSOR




M12
CONNECTOR

REV	DATE	DESCRIPTION OF CHANGE	APPRVD	TOL:	+	-	DRAWN BY	APPROVED BY	PART OF ASSY	PART No:	PROJECT:	SHEET
				X	+/1		johnh			DRUKOR0113LA-1R		A4
				X.X	+/-0.2					TITLE: TOP ASSY, 13m RECOIL DRUM, LENGTH, ANGLE & SINGLE WIRE PAYOUT		
				X.XX	+/-0.02					DRAWING No:	FILE No:	6 OF 6
										4772	4772-A.idw	REV
												A

DRAFTING STANDARD: AS1100
DO NOT SCALE DRAWING
UNLESS OTHERWISE STATED


32 West Thebarton Rd
THEBARTON
SOUTH AUSTRALIA 5031
web: www.lsirobway.com.au
PHONE: +61 8 8238 3500
FAX: +61 8 8352 1684

ELECTRONIC ANGLE SENSOR



NOTE: RIGHT HAND MOUNT SHOWN FOR INDICATION PURPOSES ONLY


TO BOOM HEAD



DRUKOR0413LAB-1
 DRUKOR0426LAB-1
 DRUKOR0430LAB-1


REV	DATE	DESCRIPTION OF CHANGE	APPR'D	DRAWN	APPROVED	PART OF ASSY	PART NO:	PROJECT:	SCALE	SHEET	REV	
				j.hart	-	-		-	N/A	1 OF 1	B	
							WIRING DETAILS					
							DRAWING No:	4579	FILE No:	4579-B.DWG		
								LSI-ROBBY 32 WEST THEBARTON RD THEBARTON 5031 SOUTH AUSTRALIA PHONE +61 8 8352 6055 FAX +61 8 8352 1684				

STEP 1




ENSURE THAT THE RECOIL DRUM IS MOUNTED VERTICALLY AND THAT THE DIRECTION THE CABLE IS PULLED OFF THE DRUM IS IN LINE WITH THE BOOM. IF IT COMES OFF AT AN ANGLE THERE IS RISK THAT IT WILL SLIP OFF THE SIDE OF THE DRUM.

STEP 2




ENSURE CABLE DOES NOT GET CAUGHT UP, STRETCHED OR PINCHED AT PIVOT AREA.


STEP 3



STEP 4




STEP 5




WRAP CABLE 1.5 TURNS AROUND THE TIE-OFF BRACKET AND CLAMP SECURELY. REMOVE EXCESS CABLE ONLY IF ATB NOT INSTALLED. IF ATB IS INSTALLED LEAVE ENOUGH CABLE TO ATTACH TO THE ATB SWITCH.

ENSURE THAT ALL CABLE GUIDES ARE IN A STRAIGHT LINE OR EXCESS WEAR ON THE CABLE WILL OCCUR.

REV	DATE	DESCRIPTION OF CHANGE	APPR'D	DRAWN	APPROVED	PART OF ASSY	PART NO.:	PROJECT:		
				S. CHAMBERS	J. KOVAL	-	-	RECOIL DRUM		
				31/10/2007	1/11/07					
				 LSI-ROBBY 32 WEST THEBARTON RD THEBARTON 5031 SOUTH AUSTRALIA PHONE +61 8 8352 6055 FAX +61 8 8352 1684				SCALE	N/A	
								TITLE:		INSTALLATION DETAILS
							DRAWING No:	DWG 3718	FILE No:	371801AA.DWG
									REV	1.0

TOL: X, +/- 1
 XX +/- 0.2
 XXX AS STATED
 DRAFTING STANDARD: AS1100
 DO NOT SCALE DRAWING
 ALL DIMENSIONS ARE IN MILLIMETERS
 UNLESS OTHERWISE STATED



NOTE:

TO ENSURE CABLE FLEETS EVENLY OVER DRUM WIDTH, THE CENTRE OF THE CABLE GUIDES MUST BE FITTED ON THE CENTRE LINE OF THE CABLE DRUM AS SHOWN.

WARNING:

IF THE ABOVE NOTE IS NOT SATISFIED, THE CABLE MAY OVER SPILL SIDES OF THE DRUM FLANGE.

REV	DATE	DESCRIPTION OF CHANGE	APPRID	DRAWN		APPROVED	PART OF ASSY	PART NO.:	PROJECT:	SCALE
				S. CHAMBERS	J. KOVAL	-	-	RECOIL DRUM		N/A
				31/10/2007	1/11/07					SHEET
										2 OF 4
										REV
										1.0


TOL:	X,	+/- 1
	XX	+/- 0.2
	XXX	AS STATED

DRAFTING STANDARD: AS1100

DO NOT SCALE DRAWING
ALL DIMENSIONS ARE IN MILLIMETERS
UNLESS OTHERWISE STATED

DRAWING NO:	DWG 3718	FILE NO:	371801AA.DWG
-------------	----------	----------	--------------




TITLE: INSTALLATION DETAILS



REV	DATE	DESCRIPTION OF CHANGE	APPR'D	DRAWN	APPROVED	PART OF ASSY	PART NO.:	PROJECT:
				S. CHAMBERS	J. KOVAL	-	-	RECOIL DRUM
				31/10/2007	1/11/07			INSTALLATION DETAILS
								SCALE N/A
								SHEET 3 OF 4
								REV
								FILE No: 371801AA.DWG
								DRAWING No: DWG 3718
								1.0

TOL: X, +/- 1
 XX, +/- 0.2
 X.XX AS STATED

DRAFTING STANDARD: AS1100
 DO NOT SCALE DRAWING
 ALL DIMENSIONS ARE IN MILLIMETERS
 UNLESS OTHERWISE STATED






CABLE GUIDE ASSEMBLY


CABLE GUIDE MOUNTING BRACKET
(SUPPLIED BY CUSTOMER)

- NOTES:**
1. RECOMMENDED MATERIAL 40X40X5mm RIGHT ANGLED STEEL PLATE.
 2. WELD THE MOUNTING BRACKET TO THE CRANE BOOM, ENSURING THAT THE LOCATION MEETS THE CRITERIA OUTLINED ON SHEET 2.
 3. BOLT THE CABLE GUIDE ASSEMBLY TO THE MOUNTING BRACKET.


REV	DATE	DESCRIPTION OF CHANGE	APP'D	TOL:	DRAWN	APPROVED	PART OF ASSY	PART NO.:	PROJECT:	SCALE	
				X +/-1	S. CHAMBERS	J. KOVAL	-	-	RECOIL DRUM	N/A	
				X.XX +/-0.2	31/10/2007	1/11/07					
				X.XX AS STATED							
				DRAFTING STANDARD: AS1100							
				DO NOT SCALE DRAWING							
				UNLESS OTHERWISE STATED							
											
					A Division of Lead Systems International						
					32 West Thebarton Rd THEBAROTON SOUTH AUSTRALIA 5031 web : www.lsirobby.com.au PH: +61 8 8238 3500 FX: +61 8 8352 1684						
					DRAWING No:		DWG 3718		FILE No:		371801AA.DWG
					TITLE:		INSTALLATION DETAILS				
					SHEET		4 OF 4				
					REV		1.0				



REV	DATE	DESCRIPTION OF CHANGE	APPR'D	DRAWN		APPROVED		PART OF ASSY	PART No:	PROJECT:	SCALE
1.1	28/05/98	REFER TO DR#451		C. HOBBY	D.G.	10/09/97	10/09/97	-	-	HRT3MM	N/A
				TOL: X +/- 1 XX +/- 0.2 XXX AS STATED				DO NOT SCALE DRAWING ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED			
								LSI-ROBBWAY 32 WEST THEBARTON RD THEBARTON 5031 SOUTH AUSTRALIA PHONE +61 8 8352 6055 FAX +61 8 8352 1884			
				A Division of Land Systems International				OVERALL DIMENSIONS			
				DRAWING No: DWG 1393				FILE No: 139301AB.DWG			
				SHEET 1 OF 1				REV 1.1			




NOTE: APPLY LOCTITE 243 TO THREAD OF GRUB SCREW.



ITEM	QTY	MATERIAL/DESCRIPTION	DWG No.	STOCK CODE (STANDARD)	STOCK CODE (MARINE S/S)
1	1	MOUNTING FRAME	DWG0885	FRADYN01	FRAHRT3MMSS
2	1	ROCKER ARM	DWG0880	ROC3MM	ROC3MMSS
3	3	SHEAVE	DWG0892	SHEH3MM###	-
4	1	PIVOT PIN	DWG0882	SHAHT01	-
5	1	SPACER	DWG0883	SPAHT08	SPAHT3MMSS
6	1	PIVOT SHEAVE PIN	DWG0881	SHAHT03	-
7	2	SHEAVE PIN	DWG0882	SHAHT02	-
8	6	WASHER	WAS20F	-	-
9	3	SPLIT PIN	PINCOIT103	-	-
10	1	SOC. HEAD GRUB SCREW M6X20	SCRM620SG	-	-
11	1	LOAD CELL	CELBTID5P	-	-
12	2	HEX HEAD BOLT	BOL1213HHZP	-	-
13	1	HEX HEAD SET SCREW	DWG0287	SCR122CZP	-
14	1	LOCK NUT	-	NUIT2HLZP	-
15	1	PACKER	DWG0884	PACHRT01	-
16	1	LANDING PAD	DWG0887	PADHRT01	-
17	2	MOUNT ANGLE BRACKET	DWG0886	BRAHRT3MMU	BRAHRT3MMSS

NOTE: ITEMS 16 & 17 ARE NOT SHOWN ON DRAWING



STANDARD HEIGHT POSITION OF SCREW (ITEM 13) IN LOAD CELL (ITEM 11)

STANDARD - DYNHRT3MM
MARINE S/S - DYNHRT3MMSS



REV	DATE	DESCRIPTION OF CHANGE	APPR'D	TOL:	DRAWN	APPROVED	PART OF ASSY	PART No:	PROJECT:	SCALE
1.2	11/01/96	REFER TO DR#125	M. OBST	X +/- 1	ER	M. OBST	-	SEE ABOVE	HRT-3MM DYNO	N/A
1.3	11/02/97	REFER TO DR#229	M. OBST	XX +/- 0.2	07/10/89	20/11/95	-	GENERAL ARRANGEMENT		SHEET N/A
1.4	28/05/98	REFER TO DR#451	M. OBST	X:XX AS STATED						1 OF 1
1.5	29/03/99	REFER TO DR#551	D.P.							
1.6	27/01/05	REFER TO DR#345	G.C.							
1.7	01/08/05	REFER TO DR#409	S.C.							

DO NOT SCALE DRAWING UNLESS OTHERWISE STATED



LSI-ROBBY
32 WEST THEBARTON RD
THEBARTON 5031
SOUTH AUSTRALIA
PHONE +61 8 8352 6055
FAX +61 8 8352 1684

DRAWING No: DWG 0875 FILE No: 087501AH.DWG
TITLE: GENERAL ARRANGEMENT




ITEM	QTY	MATERIAL/DESCRIPTION	DWG No.	STOCK CODE (STANDARD)	STOCK CODE (MARINE S/S)
1	1	SIDE PLATE-RIGHT	DWG0203	PLAHR10	PLAHR10SS
2	1	SIDE PLATE-LEFT	DWG0203	PLAHR13	PLAHR13SS
3	1	MOUNT ANGLE BRACKET RIGHT HAND	DWG0299	BRARHT04	BRARHT04SS
4	-	MOUNT ANGLE BRACKET LEFT HAND	DWG0299	BRARHT03	BRARHT03SS
5	3	SHEAVE ASSY #14 CABLE	DWG0345	SHEH32014	-
	3	OR #16 CABLE	DWG0345	SHEH32016	-
	3	OR #20 CABLE	DWG0345	SHEH32020	-
	3	OR #26 CABLE	DWG0345	SHEH32026	-
	3	OR #29 CABLE	DWG0345	SHEH32029	-
6	1	LOAD PLATE	DWG0302	PLAHR08	PLAHR08SS
7	3	SHAFT-SHEAVE	DWG0225	SHAHR12	-
8	1	ROCKER BOX	DWG0346	ROC3MAR	ROC3MARRS
9	1	SHAFT-SHEAVE-ROCKER BOX	DWG0289	SHAHR11	-
10	1	LOAD CELL ASSY-SK-WITH PLUG	-	CELRTD5P	-
11	1	SPACERS	-	CELRTD5	-
12	2	KEEPER-CABLE	DWG0301	SPAHR06	SPAHR06SS
13	2	BOLT-CELL MOUNTING 1/2"x1 3/4" SS	DWG0300	KEHRHT02	KEHRHT02SS
14	1	LOADING BOLT 1/2"x2" SS	DWG0287	SCR122CZP	-
15	1	LOCK NUT 1/2" UNF SS	-	NUT12HLSS	-
16	6	M10X100 HEX HEAD BOLT	-	BOLM1010DHG	BOLM1010DHSS
17	22	M10 HALF SIZE LOCK NUT	-	NUTM10HLG	NUTM10HSS
18	3	SPLIT PIN #4X50 SS	-	PINCOIT03	-
19	1	SOC GRUB SCREW M6X12 CUP PT	-	SCR0612SG	-
20	8	M20 FLAT WASHER	-	WASM20FZP	WASM20FSS
21	26	M10 FLAT WASHER	-	WASM10FZP	WASM10FSS
22	5	M10X120 HEX HEAD BOLT	-	BOLM10120HG	BOLM10120HSS




DYNHRT3 - STANDARD (NO SHEAVES)
 DYNHRT3 - STANDARD (INCLUDING SHEAVES)
 DYNHRT3SS - STAINLESS STEEL MARINE (NO SHEAVES)

REV	DATE	DESCRIPTION OF CHANGE	APPR'D	TOL:	DRAWN	APPROVED	PART OF ASSY	PART No:	PROJECT:	SCALE
1.0	14/09/95	ISSUED FOR MANUFACTURE		X	F. LOCKER	M. OBST	-	AS ABOVE	HRT-3 DYN0	N/A
1.1	04/01/96	ITEMS 3&4 CHANGED AS PER DR#124		XX						
1.2	27/08/97	REFER TO DR#318		X:XX						
1.3	29/03/99	REFER TO DR#561		AS STATED						
1.4	27/01/05	REFER TO DR#345								



DO NOT SCALE DRAWING UNLESS OTHERWISE STATED		LSI-ROBWAY 32 WEST THEEBARTON RD THEEBARTON 5031 SOUTH AUSTRALIA PHONE +61 8 8352 6055 FAX +61 8 8352 1684	
DRAWING No:	DWG 0422	FILE No:	042201AE.DWG
REV	1.4	SHEET	1 OF 2



3RD ANGLE



REV	DATE	DESCRIPTION OF CHANGE	APPR'D	TOL:	DRAWN	APPROVED	PART OF ASSY	PART No:	PROJECT:	SCALE
1.0	14/09/95	ISSUED FOR MANUFACTURE		X X +/- 1	F. LOCKER	M. OBST	-	AS ABOVE	HRT-3 DYNO	N/A
1.1	04/01/96	ITEMS 3&4 CHANGED AS PER DR#124	M.O.	X:XX AS STATED	14/09/95	14/09/95		GENERAL ARRANGEMENT	042201AE.DWG	SHEET 2 OF 2
1.2	27/08/97	REFER TO DR#318	M.O.							
1.3	29/03/99	REFER TO DR#561	M.G.							
1.4	27/01/05	REFER TO DR#345	G.C.							
				DO NOT SCALE DRAWING UNLESS OTHERWISE STATED			LSI-ROBBY 32 WEST THEBARTON RD THEBARTON 5031 SOUTH AUSTRALIA PHONE +61 8 8352 6055 FAX +61 8 8352 1684		FILE No:	REV
								DWG 0422	042201AE.DWG	1.4



ITEM	QTY	MATERIAL/DESCRIPTION	DWG No.	STOCK CODE (STANDARD)	STOCK CODE (MARINE S/S)
1	1	SIDE PLATE-RIGHT	DWG0203	PLAHR10	PLAHR10SS
2	1	SIDE PLATE-LEFT	DWG0203	PLAHR13	PLAHR13SS
3	1	MOUNT ANGLE BRACKET RIGHT HAND	DWG0299	BRAHR104	BRAHR104SS
4	-	MOUNT ANGLE BRACKET LEFT HAND	DWG0299	BRAHR103	BRAHR103SS
5	3	SHEAVE ASSY Ø14 CABLE	DWG0345	SHEH32014	-
	3	OR Ø16 CABLE	DWG0345	SHEH32016	-
	3	OR Ø20 CABLE	DWG0345	SHEH32020	-
	3	OR Ø26 CABLE	DWG0345	SHEH32026	-
	3	OR Ø29 CABLE	DWG0345	SHEH32029	-
6	1	LOAD PLATE	DWG0302	PLAHR108	PLAHR108SS
7	3	SHAFT-SHEAVE	DWG0225	SHAHR12	-
8	1	ROCKER BOX	DWG0346	ROC3MAR	ROC3MARSS
9	1	SHAFT-SHEAVE-ROCKER BOX	DWG0289	SHAHR11	-
10	1	LOAD CELL ASSY-5K-WITH PLUG	-	CELBTD5P	-
	1	LOAD CELL ASSY-5K-NO PLUG	-	CELBTD5	-
11	6	SPACERS	DWG0301	SPAHR106	SPAHR106SS
12	2	KEEPER-CABLE	DWG0300	KEHR102	KEHR102SS
13	2	BOLT-CELL MOUNTING 1/2"x1 3/4" SS	-	BOL1213HSS	-
14	1	LOADING BOLT 1/2"x2" SS	DWG0287	SCR122CZP	-
15	1	LOCK NUT 1/2" UNF SS	-	NUT12HLSS	-
16	6	M10X100 HEX HEAD BOLT	-	BOLM10100HG	BOLM10100HSS
17	2	M10 HALF SIZE LOCK NUT	-	NUTM10HLG	NUTM10HSS
18	3	SPLIT PIN Ø4X50 SS	-	PINCO1103	-
19	1	SOC GRUB SCREW M6X12 CUP PT	-	SCRM612SG	-
20	8	M20 FLAT WASHER	-	WASM20FZP	WASM20FSS
21	26	M10 FLAT WASHER	-	WASM10FZP	WASM10FSS
22	5	M10X120 HEX HEAD BOLT	-	BOLM10120HG	BOLM10120HSS

NOTE: APPLY LOCTITE 243 TO THREAD OF GRUB SCREW.

REV	DATE	DESCRIPTION OF CHANGE	APP'R'D
1.1	04/01/96	CORRECT PART NO 3 & 4 AS PER DR#124	M.O.
1.2	22/07/97	REFER TO DR#318	M.O.
1.3	20/07/98	REFER TO DR#494	M.O.
1.4	29/03/99	REFER TO DR#551	M.G.
1.5	27/01/05	REFER TO DR#345	G.C.
1.6	01/08/05	REFER TO DR#409	S.C.

TOL: X +/- 1
 XX +/- 0.2
 XXX AS STATED



DO NOT SCALE DRAWING
 UNLESS OTHERWISE STATED

DRAWN	APPROVED	PART OF ASSY
F. LOCKER 15/09/95	M. OBST 15/09/95	-

TITLE:	PART No.:	PROJECT:	SCALE
EXPLODED VIEW AND PARTS LIST FOR HRT-3 DYNO (VERTICAL MOUNT)	AS ABOVE	HRT-3 DYNO	N/A
DRAWING No: DWG 0104			SHEET 1 OF 1
FILE No: 010401AG.DWG			REV 1.6



DYNHRT3 - STANDARD (NO SHEAVES)
 DYNHRT3 - STANDARD (INCLUDING SHEAVES)
 DYNHRT3SS - STAINLESS STEEL MARINE (NO SHEAVES)



ITEM	QTY	MATERIAL/DESCRIPTION	DWG No.	STOCK CODE (STANDARD)	STOCK CODE (MARINE S/S)
1	1	SIDE PLATE-RIGHT	DWG0203	PLAHR10	PLAHR10SS
2	1	SIDE PLATE-LEFT	DWG0203	PLAHR13	PLAHR13SS
3	3	SHEAVE ASSY Ø14 CABLE	DWG0345	SHEH32014	-
3	3	OR Ø16 CABLE	DWG0345	SHEH32016	-
3	3	OR Ø20 CABLE	DWG0345	SHEH32020	-
3	3	OR Ø26 CABLE	DWG0345	SHEH32026	-
3	3	OR Ø29 CABLE	DWG0345	SHEH32029	-
4	1	LOAD PLATE	DWG0302	PLAHR108	PLAHR108SS
5	3	SHAFT-SHEAVE	DWG0225	SHAHR12	-
6	1	ROCKER BOX	DWG0346	ROC3MAR	ROC3MARSS
7	1	SHAFT-SHEAVE-ROCKER BOX	DWG0289	SHAHR11	-
8	1	LOAD CELL ASSY-5K-WITH PLUG	-	CELBTD5P	-
1	1	LOAD CELL ASSY-5K-NO PLUG	-	CELBTD5	-
9	6	SPACERS	DWG0301	SPAHR106	SPAHR106SS
10	2	KEEPER-CABLE	DWG0300	KEEHR102	KEEHR102SS
11	2	BOLT-CELL MOUNTING 1/2"x1 3/4" SS	-	BOL1213HHSS	-
12	1	LOADING BOLT 1/2"x2" SS	DWG0287	SCR122CZP	-
13	1	LOCK NUT 1/2" UNF SS	-	NUT12HLSS	-
14	6	M10X100 HEX HEAD BOLT	-	BOLM10100HG	BOLM10100HSS
15	22	M10 HALF SIZE LOCK NUT	-	NUTM10HLG	NUTM10HSS
16	3	SPLIT PIN Ø4X50 SS	-	PINCOTT03	-
17	1	SOC GRUB SCREW M6X12 CUP PT	-	SCRM612SG	-
18	8	M20 FLAT WASHER	-	WASM20FZP	WASM20FSS
19	26	M10 FLAT WASHER	-	WASM10FZP	WASM10FSS

NOTE: APPLY LOCTITE 243 TO THREAD OF GRUB SCREW.

- DYNHRT3 - STANDARD (NO SHEAVES)
- DYNHRT3 - STANDARD (INCLUDING SHEAVES)
- DYNHRT3SS - STAINLESS STEEL MARINE (NO SHEAVES)



REV	DATE	DESCRIPTION OF CHANGE	APPR'D	TOL:	DRAWN	APPROVED	PART OF ASSY	PART No.:	PROJECT:	SCALE
1.1	11/01/96	CORRECT PART NO. 14 AS PER DR#125	M.O.	X XX XXX	F. LOCKER	M. OBST	-	AS ABOVE	HRT-3 DYNO	N/A
1.2	22/07/97	REFER TO DR#318	M.O.	+/- 0.2 AS STATED	15/09/95	15/09/95	-	EXPLODED VIEW AND PARTS LIST FOR HRT-3 DYNO (HORIZONTAL MOUNT)	SHEET 1 OF 1	
1.3	26/03/99	REFER TO DR#551	M.G.							
1.4	27/01/05	REFER TO DR#345	G.C.							
1.5	01/08/05	REFER TO DR#409	S.C.							

DO NOT SCALE DRAWING UNLESS OTHERWISE STATED



LSI-ROBWAY
32 WEST THEBARTON RD
THEBARTON 5031
SOUTH AUSTRALIA
PHONE +61 8 8352 6055
FAX +61 8 8352 1684




DWG 0786 FILE No: 078601AF.DWG



NOTE: APPLY LOCTITE 243 TO THREAD OF GRUB SCREW.

ITEM	QTY	MATERIAL/DESCRIPTION	DWG No.	STOCK CODE (STANDARD)	STOCK CODE (MARINE S/S)
1	1	SIDE PLATE-RIGHT	DWG0203	PLAHR10	PLAHR10SS
2	1	SIDE PLATE-LEFT	DWG0203	PLAHR13	PLAHR13SS
3	3	SHEAVE ASSY ϕ 14 CABLE	DWG0345	SHEH32014	-
3	3	OR ϕ 16 CABLE	DWG0345	SHEH32016	-
3	3	OR ϕ 20 CABLE	DWG0345	SHEH32020	-
3	3	OR ϕ 26 CABLE	DWG0345	SHEH32026	-
3	3	OR ϕ 29 CABLE	DWG0345	SHEH32029	-
4	1	LOAD PLATE	DWG0302	PLAHR108	PLAHR108SS
5	3	SHAFT-SHEAVE	DWG0225	SHAHR112	-
6	1	ROCKER BOX	DWG0346	ROCC3MAR	ROCC3MARSS
7	1	SHAFT-SHEAVE-ROCKER BOX	DWG0289	SHAHR111	-
8	1	LOAD CELL ASSY-5K-WITH PLUG	-	CELBTD5P	-
8	1	LOAD CELL ASSY-5K-NO PLUG	-	CELBTD5	-
9	6	SPACERS	DWG0301	SPAHR106	SPAHR106SS
10	2	KEEPER-CABLE	DWG0300	KEHR102	KEHR102SS
11	2	BOLT-CELL MOUNTING 1/2"x1 3/4" SS	-	BOL1213HSS	-
12	1	LOADING BOLT 1/2"x2" SS	DWG0287	SCRI122CZP	-
13	1	LOCK NUT 1/2" UNF SS	-	NUT12HSS	-
14	7	M10X100 HEX HEAD BOLT	-	BOLM10100HG	BOLM10100HSS
15	22	M10 HALF SIZE LOCK NUT	-	NUTM10HLG	NUTM10HSS
16	3	SPLIT PIN ϕ 4X50 SS	-	PINCOT103	-
17	1	SOC GRUB SCREW M6X12 CUP PT	-	SCRM612SG	-
18	8	M20 FLAT WASHER	-	WASM20FZP	WASM20FSS
19	22	M10 FLAT WASHER	-	WASM10FZP	WASM10FSS
20	4	M10X120 HEX HEAD BOLT	-	BOLM10120HG	BOLM10120HSS
21	2	LANDING PAD	DWG0303	PADHRT01	-

REV	DATE	DESCRIPTION OF CHANGE	APPR'D	TOL:	DRAWN	APPROVED	PART OF ASSY	PART No.:	PROJECT:	SCALE
1.1	11/01/96	CORRECT PART NO 14 AS PER DR#125	M.O.	X +/- 1	F. LOCKER	M. OBST	-	AS ABOVE	HRT-3 DYNO	N/A
1.2	30/10/97	REFER TO DR#318	M.O.	XX +/- 0.2	15/09/95	15/09/95	-	EXPLODED VIEW AND PARTS LIST FOR HRT-3	DYNO (HORIZONTAL MOUNT WITH LANDING PADS)	SHEET N/A
1.3	26/03/99	REFER TO DR#551	M.G.	X:XX AS STATED	LSI-ROBWAY 32 WEST THEBARTON RD THEBARTON 5031 SOUTH AUSTRALIA PHONE +61 8 8352 6055 FAX +61 8 8352 1684		-	DYNHRT3 - STANDARD (NO SHEAVES)	DYNHRT3 - STANDARD (INCLUDING SHEAVES)	1 OF 1
1.4	27/01/05	REFER TO DR#345	G.C.		A Division of Loyal Systems International		-	DYNHRT3SS - STAINLESS STEEL MARINE (NO SHEAVES)		REV 1.5
1.5	01/08/05	REFER TO DR#409	S.C.		DO NOT SCALE DRAWING UNLESS OTHERWISE STATED		-			





ITEM	QTY	MATERIAL/DESCRIPTION	DWG No.	STOCK CODE
1	1	SIDE PLATE-RIGHT	DWG0203	PLAHR10
2	1	SIDE PLATE-LEFT	DWG0203	PLAHR13
3	1	MOUNT ANGLE BRACKET RIGHT HAND	DWG0299	BRARHT04
4	1	MOUNT ANGLE BRACKET LEFT HAND	DWG0299	BRARHT03
5	6	SHEAVE ASSEMBLY Ø14 CABLE	DWG0345	SHEH32014
6	OR	Ø16 CABLE	DWG0345	SHEH32016
6	OR	Ø20 CABLE	DWG0345	SHEH32020
6	OR	Ø26 CABLE	DWG0345	SHEH32026
6	OR	Ø29 CABLE	DWG0345	SHEH32029
6	2	LOAD PLATE	DWG0302	PLAHR108
7	3	SHAFT-SHEAVE	DWG0290	SHAHR15
7	2	ROCKER BOX	DWG0346	ROCG3MAR
8	2	SHAFT-SHEAVE-ROCKER BOX	DWG0289	SHAHR11
10	2	LOAD CELL ASSY-5K-WITH PLUG	-	CELBTD5P
11	2	LOAD CELL ASSY-5K-NO PLUG	-	CELBTD5
11	12	SPACERS	DWG0301	SPAHR106
12	4	KEEPER-CABLE	DWG0300	KEEHR102
13	4	BOLT-CELL MOUNTING 1/2"x1 3/4" ZP	-	BOLT1213HHZP
14	2	LOADING BOLT 1/2"x2" ZP	-	SCR122CZP
15	2	LOCK NUT 1/2" UNF GALV	-	NUT12HLZP
16	6	M10X180 BOLT HEX HEAD GALV	-	BOLM10180HG
17	22	M10 HALF SIZE LOCK NUT GALV	-	NUTM10HLG
18	3	SPLIT PIN Ø4X50 SS	-	PINCOT103
19	2	SOC GRUB SCREW M6X12 CUP PT SS	-	SCRM612SG
20	16	M20 FLAT WASHER ZP	-	WASW20FZP
21	30	M10 FLAT WASHER ZP	-	WASW10FZP
22	5	M10X200 BOLT HEX HEAD GALV	-	BOLM10200HG
23	1	CENTRE PLATE	DWG0367	PLAHR118
8	2	ROCKER BOX	DWG0823	ROCK3M0823
20	12	M20 FLAT WASHER SS	-	WASW20SS
24	4	BUSH-SHOULDERED	DWG0824A	BUSHRT03

FOR THE HEAVY DUTY MARINESED MODEL THE FOLLOWING ALTERATIONS TO THE ABOVE PARTS LIST ARE TO BE MADE:

DYNHRT32 NO SHEAVES
 DYNHRT32S INCLUDING SHEAVES
 DYNHRTM32 MARINESED NO SHEAVES

REV	DATE	DESCRIPTION OF CHANGE	APPR'D
1.0	12/09/95	ISSUED FOR MANUFACTURE	
1.1	08/01/96	CORRECT PART NO 3 & 4 AS PER DR#124	M.O.
1.2	22/07/97	REFER TO DR#318	M.O.
1.3	02/10/98	REFER TO DR#494	D.P.
1.4	29/03/99	REFER TO DR#551	G.C.
1.5	01/08/05	REFER TO DR#409	S.C.

TO: X +/ - 1 XX +/- 0.2 XXX AS STATED	DRAWN F. LOCKER 04/08/94	APPROVED M. OBST 04/08/94	PART OF ASSY -
DO NOT SCALE DRAWING UNLESS OTHERWISE STATED		LSI-ROBBY 32 WEST THEBARTON RD SOUTH AUSTRALIA 5031 PHONE +61 8 8352 6055 FAX +61 8 8352 1684	TITLE: EXPLODED VIEW AND PARTS LIST FOR HRT3-2 DYNO (VERTICAL MOUNT)
	DRAWING No: DWG 0353	PROJECT: HRT-3-2 DYNO	SCALE N/A SHEET 1 OF 1 REV 1.5



ITEM	QTY	MATERIAL/DESCRIPTION	DWG No.	STOCK CODE
1	1	SIDE PLATE-RIGHT	DWG0203	PLAHR10
2	1	SIDE PLATE-LEFT	DWG0203	PLAHR13
3	1	MOUNT ANGLE BRACKET-RH	DWG0299	BRahrT04
4	1	MOUNT ANGLE BRACKET-LH	DWG0299	BRahrT03
5	6	SHEAVE ASSEMBLY Ø14 CABLE	DWG0345	SHEH32014
6	6	OR Ø16 CABLE	DWG0345	SHEH32016
6	6	OR Ø20 CABLE	DWG0345	SHEH32020
6	6	OR Ø26 CABLE	DWG0345	SHEH32026
6	6	OR Ø29 CABLE	DWG0345	SHEH32029
6	2	LOAD PLATE	DWG0302	PLAHR108
7	3	SHAFT-SHEAVE	DWG0290	SHAHR15
8	2	ROCKER BOX	DWG0346	ROCSMAR
9	2	SHAFT-SHEAVE-ROCKER BOX	DWG0289	SHAHR11
10	2	LOAD CELL ASSY-5K-WITH PLUG	-	CELBTD5P
2	2	LOAD CELL ASSY-5K-NO PLUG	-	CELBTD5
11	12	SPACERS	DWG0301	SPhAR106
12	4	KEEPER-CABLE	DWG0300	KEEHR102
13	4	BOLT-CELL MOUNTING 1/2"x1 3/4" ZP	-	BOL1213HHZP
14	2	LOADING BOLT 1/2"x2" ZP	-	SCR122CZP
15	2	LOCK NUT 1/2" UNF ZP	-	NUT12H1ZP
16	6	M10X180 BOLT HEX HEAD GALV	-	BOLM10180HG
17	22	M10 HALF SIZE LOCK NUT	-	NUTM10HLG
18	3	SPLIT PIN Ø4X50 SS	-	PINCOTT103
19	2	SOC GRUB SCREW M6X12 CUP PT SS	-	SCRM612SG
20	16	M20 FLAT WASHER ZP	-	WASM20FZP
21	8	M10 FLAT WASHER ZP	-	WASM10FZP
22	5	M10X200 BOLT HEX HEAD GALV	-	BOLM10200HG
23	1	CENTRE PLATE	DWG0367	PLAHR18

FOR THE HEAVY DUTY MARINESED MODEL THE FOLLOWING ALTERATIONS TO THE ABOVE PARTS LIST ARE TO BE MADE.


8	2	ROCKER BOX	DWG0823	ROCH3M0823
20	12	M20 FLAT WASHER SS	-	WASM20SS
24	4	BUSH-SHOULDERED	DWG0824A	BUSHHR103

DYNHRT32 NO SHEAVES
 DYNHRT32S INCLUDING SHEAVES
 DYNHRTM32 MARINESED NO SHEAVES


REV	DATE	DESCRIPTION OF CHANGE	APP'R'D	DRAWN	APPROVED	PART OF ASSY	PART No:	PROJECT:	SCALE
1.0	14/09/95	ISSUED FOR MANUFACTURE		F. LOCKER	M. OBST	-	AS ABOVE	HRT-3-2 DYN0	N/A
1.1	07/01/96	CORRECT AS PER DR#124							SHEET
1.2	29/03/99	REFER TO DR#551							1 OF 1

TO: X +/- 1 XX +/- 0.2 XXX AS STATED		ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED
DO NOT SCALE DRAWING UNLESS OTHERWISE STATED		

LSI LSI-ROBWAY 32 WEST THEBARTON RD SOUTH AUSTRALIA PHONE +61 8 8352 6055 FAX +61 8 8352 1684	DRAWING No: DWG 0552 FILE No: 055201AC.DWG
---	---



ITEM	QTY	MATERIAL/DESCRIPTION	DWG No.	STOCK CODE
1	1	MOUNTING BRACKET	DWG0368	BRAMAA0368
2	2	UNIVERSAL JOINT	DWG0369	JOINU0369
3	1	OUTER TUBE	DWG0372	TUB00372
4	2	TELESCOPIC ARM	DWG0373	ARMTAA0373
5	2	BOLT H.T. 3/4"UNF X 5" LONG	-	BOL34U5ZP
6	2	BOLT H.T. 3/4" X 4" LONG	-	BOL34U4ZP
7	4	NYLOC NUT 3/4"UNF	-	NUTNYU34ZP
8	8	WASHER 3/4" I/D	-	WAS34FZP
9	2	SPACER - REQ'D FOR HRT4 ONLY	DWG0663	SPAAA0663




IMPORTANT :-
When altering this drawing ensure that the changes are also included on drawing DWG0371


FINISH - PRIMER - POLYZINC 660
COATING - INTERPRON 610 MATT BLACK

REV	DATE	DESCRIPTION OF CHANGE	APPR'D	DRAWN	APPROVED	PART OF ASSY	PART No:	PROJECT:	SCALE	SHEET
1.0	16/10/01	CONVERTED TO AUTOCAD FORMAT	S.C.	F. LOCKER	M. OBST	-	ARMART0370	ARTICULATED ARM	N/A	1 OF 1
1.1	25/08/03	REFER TO DR#186	S.C.	10/11/94	10/11/94	-				REV
										1.1


TOL: X +/- 1 XX +/- 0.2 XXX AS STATED		LSI-ROBWAY 32 WEST THEBARTON RD THEBARTON 5031 SOUTH AUSTRALIA PHONE +61 8 8352 6055 FAX +61 8 8352 1684
DO NOT SCALE DRAWING ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED		
LSI ROBWAY <small>A Division of Lead Systems International</small>		

DWG 2468T (Sheet 1 of 3)
TYPICAL INSTALLATION OF DYNO
ON TELESCOPIC CRANE






DWG 2468T (Sheet 2 of 3)
TYPICAL INSTALLATION OF DYNO
ON TELESCOPIC CRANE




1. REFERED ANGLES OF THIS DRAWING ARE FOR 19mm ROPE . REFER TO TABLE BELOW FOR ALTERNATIVE ROPE DIAMETERS.
2. ϕ OF DYNAMOMETER DOES NOT HAVE TO BE ONE OF BOOM
3. IF FLEET ANGLES CANNOT BE KEPT WITHIN THE PRESCRIBED TOLERANCES THEN THE ARTICULATED ARM DESCRIBED IN THIS MANUAL SHOULD BE FITTED




WHEN POSITIONING DYNAMOMETER ON END OF BOOM CHECK THAT WINCH CABLE FLEET ANGLE IS WITHIN VALUE AS SHOWN IN TABLE. ϕ NOT DEFLECTED MORE THAN STATED ANGLE FROM ROPE'S NORMAL LINE.

ROPE	FLEET ANGLE
13mm	4.7°
14.5mm	4.2°
16mm	3.7°
19mm	2.2°
20mm	1.8°
25mm	1.2°
28mm	1.1°
32mm	1.0°






PLAN VIEW

DWG 2468T (Sheet 3 of 3)
TYPICAL INSTALLATION OF DYNO
ON TELESCOPIC CRANE



Parts List

ITEM	QTY	DESCRIPTION	DWG No.	PART NUMBER
18	2	CABLE TIES		TIE200BK





REV	DATE	DESCRIPTION OF CHANGE	APPRVD	TOL:	DRAWN BY	APPROVED BY	PART OF ASSY	PART No:	PROJECT:
1.1	16/07/10	EXPLORED VIEW ADDED REFER PCR#322	A.A.	X: X +/-1 X:X +/-0.2 X:XX +/-0.02	S. CHAMBERS	A. CANLAS	-	SWIBB5	BB5 ATB SWITCH
1.2	14/01/2011	REFER TO PCR#366	A.A.	DO NOT SCALE DRAWING ALL DIMENSIONS ARE IN MILLIMETERS UNLESS OTHERWISE STATED	19/04/2005	19/04/2005		ASSY, BB5 DIMENSIONAL DETAIL	SCALE N/A
1.3	24-1-14	REFER TO ECN 543	J.H						SHEET 1 OF 2
								DRAWING No: 2934	REV 1.3
								FILE No: 293401AD.idw	

32 West Thebarton Rd
THEBARTON
SOUTH AUSTRALIA 5031
web : www.lsirobway.com.au
PHONE: +61 8 8238 3500
FAX: +61 8 8352 1684

A Division of Lead Systems International

©copyright robway 2005

TELESCOPIC BOOM SINGLE CORE PAYOUT CABLE APPLICATION



ATB SWITCH CONNECTION FOR MAIN AND FLY

REV	DATE	DESCRIPTION OF CHANGE	APPR'D	TOL:	+	-	1	DRAWN	APPROVED	PART OF ASSY	PART No:	PROJECT:	SCALE
1.1	03/08/05	REFER TO DR#421	A.C.	X X	X X	X X	AS STATED	S. CHAMBERS	A. CANLAS	-	-	-	N/A
				X:XX				10/07/01	10/07/01				SHEET
													1 OF 3
													REV
													1.1

DO NOT SCALE DRAWING
UNLESS OTHERWISE STATED


LSI-ROBWAY
32 WEST THEBARTON RD
THEBARTON, 5031
SOUTH AUSTRALIA
PHONE +61 8 8352 6055
FAX +61 8 8352 1684

TITLE:
ATB SWITCH
INSTALLATION DETAILS

DRAWING No: DWG 0667

FILE No: 066701AB.DWG

TELESCOPIC BOOM TWO CORE PAYOUT CABLE APPLICATION




REV	DATE	DESCRIPTION OF CHANGE	APPR'D	TOL:	+	-	1	DRAWN	APPROVED	PART OF ASSY	PART No:	PROJECT:	SCALE
1.1	03/08/05	REFER TO DR#421	A.C.	X	X	X	X	S. CHAMBERS	A. CANLAS	-	-	-	N/A
				X:XX	AS	STATED		10/07/01	10/07/01				SHEET
													2 OF 3
													REV
													1.1

DO NOT SCALE DRAWING UNLESS OTHERWISE STATED

LSI ROBBYWAY
 32 WEST THEBARTON RD
 THEBARTON, 5031
 SOUTH AUSTRALIA
 PHONE +61 8 8352 6055
 FAX +61 8 8352 1684

DRAWING No: DWG 0667 FILE No: 066701AB.DWG



TITLE: ATB SWITCH INSTALLATION DETAILS




3RD ANGLE

WIRING DETAIL

(NPN - NORMALLY OPEN)



2 X LOCKNUTS
SUPPLIED WITH PROX.
SWITCH.




M30 X 1.5 PITCH

REV	DATE	DESCRIPTION OF CHANGE	APPR'D	TOL:	DO NOT SCALE DRAWING UNLESS OTHERWISE STATED	DRAWN	APPROVED	PART OF ASSY	PART No:	PROJECT:	SCALE
				X X +/- 1		S. CHAMBERS	A. CAULAS	-	SWIPROX02	PROXIMITY SWITCH	N/A
				X:XX +/- 0.2		10/07/01	10/07/01		DIMENSIONAL DETAILS		SHEET
				X:XX AS STATED						DWG 2461	246101AA.DWG
											REV
											1.0





LSI-ROBWAY
32 WEST THEBARTON RD
THEBARTON, 5031
SOUTH AUSTRALIA
PHONE +61 8 8352 6055
FAX +61 8 8352 1684



WIRING DETAIL

(PNP - NORMALLY OPEN / NORMALLY CLOSED)



2 X LOCKNUTS
SUPPLIED WITH PROX.
SWITCH.

REV	DATE	DESCRIPTION OF CHANGE	APPR'D	DRAWN			APPROVED	PART OF ASSY	PART No:	PROJECT:	SCALE
				S. CHAMBERS					SWIPROX03	PROXIMITY SWITCH	N/A
				10/07/01					TITLE: DIMENSIONAL DETAILS		SHEET 1 OF 1
									DWG 2462	FILE No: 246201AA.DWG	REV 1.0

TOL: X +/- 1
X.X +/- 0.2
X.XX AS STATED

DO NOT SCALE DRAWING
ALL DIMENSIONS ARE IN MILLIMETERS
UNLESS OTHERWISE STATED




LSI-ROBBWAY
32 WEST THEBARTON RD
THEBARTON 5031
SOUTH AUSTRALIA
PHONE +61 8 8352 6055
FAX +61 8 8352 1884

A Division of Lead Systems International

RCI SLEW SWITCH MOUNTING (WHERE REQUIRED)

TO RCI SYSTEM KEYSWITCH BOX OR CONTROL UNIT




BOLTED TO CARRIER

NOTE 1 SUGGEST SCHMERSAL BRAND TYPE IFL 10-30-10Z1PKG
 NOTE 1 PROXIMITY SWITCH MAY BE MOUNTED HORIZONTAL

ROBBY SAFETY SYSTEMS P/L CR 382 003

DRAWN: JAW	CHECKED:	DATE: 0-11-93
CUSTOMER: ICI MANUALS		EXAMINED/INCD
ICI SLEW SWITCH MOUNTING		
FILE NO: 930050		DWG: 930050
		REV: No

Typical Slew/Proximity Switch Application



Therefore a truth table is;

sw1	sw2	condition
c	c	over-rear
c	o	over-side
o	o	over-front

broken cables over-front, least capacity.

