



## Specialist Crane Vision Systems - Onshore and Offshore

Cost-effective solutions / Worldwide support / Quality and innovation




Robway provides specialist crane vision systems for onshore and offshore applications, helping to increase the safety and efficiency of the crane and its operator - both on and off the job site.

- ▲ Best possible image in all conditions
- ▲ ISO/TS 16949:2009 and ISO 9001:2008
- ▲ Shock and vibration-proof
- ▲ 100% waterproof to IP69K

Explosion protected (Ex) camera systems are important in CCTV systems for safety in hazardous areas, offering optimal overview to operators in situations that have an explosion risk.

- ▲ Certified for zones 1, 2, 21 and 22, ATEX and IECEx
- ▲ Can be combined with third party systems



# Specialist Crane Vision Systems



## Winchview



WV7200

On the larger types of telescopic cranes, direct vision from the cabin is limited. The monitor used for load view can simultaneously be used by the operator to switch cameras and observe Winchview.



## Rearview



RV7520 / HD

A Rearcam positioned on the rear end of the upper carriage or on the under carriage, enables the operator to see accurately behind the crane.



LV7010 / LV7015 / LV7020 / LV7025

## Loadview

The crane operator does not always have optimal vision of the crane's hook and load. The Loadcam fitted to the tip of the telescopic boom provides a clear image of the hook's position which can be zoomed in on for more detail.



## CornerEye

CornerEye offers a complete and detailed view of 270° of the area around the cabin



## Loadview

V7080 / V7085



## Loadview

LV7030 / LV7035

The crane operator can immediately see on the monitor when a lifting operation could become dangerous. They can take correct action immediately and prevent accidents.

Misunderstandings are reduced as the operator can verify instructions from the signalman using the Loadcam system.

## Rearview

RV7520

View on the rear boom is becoming increasingly necessary on large building sites that have various types of cranes working together. The load view monitor can be used simultaneously with a Rearcam. With just one button, the operator is able to switch between both cameras.



Robway Safety Pty Ltd 32 West Thebarton Road, Thebarton South Australia, Australia 5031  
Tel + 61 8 8238 3500 Fax + 61 8 8352 1684 Email sales@robway.com www.robway.com